


1918  
PRICE LIST

Effective August 1, 1917

Prices and Terms Subject to Change Without Notice

*Le Roy*  
Le Roy and Cambridge  
Plows, Implements and Repairs



Manufactured by

Le Roy Plow Company

LE ROY, N. Y., U. S. A.

For Index see page 16

*G. F. Gates*

*R. F. D. Whitesboro, N. Y.*

## 2 LIST PRICES ON LE ROY WALKING AND SULKY PLOWS AND IMPLEMENTS.

| Number | Beams | Moldboard | With Clevis Only | With Wheel and Clevis | Full Ripped with Colter or Jointer | Number    | Beams | Moldboard | With Clevis Only | With Wheel and Clevis | Full Ripped with Clevis or Jointer |
|--------|-------|-----------|------------------|-----------------------|------------------------------------|-----------|-------|-----------|------------------|-----------------------|------------------------------------|
| 2 1/2  | Cast  | Chill     | 12.50            | 14.25                 |                                    | 108       | Steel | Chill     | 19.00            | 20.75                 | 24.25                              |
| 6 1/2  | Wood  | "         | 12.00            | 13.50                 |                                    | 108       | "     | Steel     | 21.00            | 22.75                 | 26.25                              |
| 7      | "     | "         | 13.50            | 15.00                 | 17.75                              | 109       | "     | Chill     | 20.00            | 21.75                 | 25.25                              |
| 8      | "     | "         | 13.50            | 15.00                 | 17.75                              | 109       | "     | Steel     | 22.00            | 23.75                 | 27.25                              |
| 9      | "     | "         | 19.00            | 20.75                 | 24.25                              | 110       | "     | Chill     | 21.00            | 22.75                 | 26.25                              |
| 9      | "     | Steel     | 21.00            | 22.75                 | 26.25                              | 110       | "     | Steel     | 23.00            | 24.75                 | 28.25                              |
| 10     | "     | Chill     | 20.00            | 21.75                 | 25.25                              | 112       | "     | Chill     | 23.00            | 24.75                 | 28.25                              |
| 10     | "     | Steel     | 22.00            | 23.75                 | 27.25                              | 112       | "     | Steel     | 25.00            | 26.75                 | 30.25                              |
| 12     | "     | Chill     | 21.00            | 22.75                 | 26.25                              | 114       | "     | Chill     | 23.00            | 24.75                 | 28.25                              |
| 12     | "     | Steel     | 23.00            | 24.75                 | 28.25                              | 114       | "     | Steel     | 25.00            | 26.75                 | 30.25                              |
| 14     | "     | Chill     | 22.00            | 23.75                 | 27.25                              | 209       | "     | Sol. St'l | 21.50            | 23.25                 | 26.75                              |
| *16    | "     | "         | 12.50            | 14.00                 |                                    | 209       | "     | S C. St'l | 24.00            | 25.75                 | 29.25                              |
| 21     | Cast  | "         | 16.50            | 18.25                 | 21.75                              | 210       | "     | S C. St'l | 25.00            | 26.75                 | 30.25                              |
| 21     | "     | Steel     | 18.50            | 20.25                 | 23.75                              | 508       | "     | Chill     | 19.00            | 20.75                 | 24.25                              |
| 22     | "     | Chill     | 17.50            | 19.25                 | 22.75                              | 508       | "     | Steel     | 21.00            | 22.75                 | 26.25                              |
| 22     | "     | Steel     | 19.50            | 21.25                 | 24.75                              | 509       | "     | Chill     | 20.00            | 21.75                 | 25.25                              |
| *30    | Steel | Sol. St'l |                  |                       | 30.50                              | 509       | "     | Steel     | 22.00            | 23.75                 | 27.25                              |
| *30    | "     | S C. St'l |                  |                       | 33.00                              | 510       | "     | Chill     | 21.00            | 22.75                 | 26.25                              |
| *31    | "     | Sol. St'l | 26.00            | 27.75                 |                                    | 510       | "     | Steel     | 23.00            | 24.75                 | 28.25                              |
| *31    | "     | S C. St'l | 28.50            | 30.25                 |                                    | 2-W. Sul. |       |           |                  |                       |                                    |
| 32     | "     | Sol. St'l | 23.00            | 24.75                 |                                    | 70        | "     | Chill     |                  |                       | 120.00                             |
| 32     | "     | Sol. St'l | 23.00            | 24.75                 |                                    | 70        | "     | Steel     |                  |                       | 124.00                             |
| 32     | "     | S C. St'l | 25.50            | 27.25                 |                                    | 71        | "     | Chill     |                  |                       | 121.50                             |
| *33    | Cast  | Chill     | 20.50            | 22.25                 |                                    | 71        | "     | Steel     |                  |                       | 125.50                             |
| 34     | "     | "         | 18.00            | 19.75                 |                                    | 73        | "     | Chill     |                  |                       | 123.00                             |
| *35    | "     | "         |                  |                       | 26.00                              | 73        | "     | Steel     |                  |                       | 127.00                             |
| *40    | Steel | Sol. St'l |                  |                       | 29.00                              | 92        | "     | "         |                  |                       | 125.00                             |
| *40    | "     | S C. St'l |                  |                       | 30.75                              | 93        | "     | "         |                  |                       | 128.00                             |
| *41    | "     | Sol. St'l | 24.00            | 25.75                 |                                    | 1-W. Sul. |       |           |                  |                       |                                    |
| *41    | "     | S C. St'l | 26.00            | 27.75                 |                                    | 70        | "     | Chill     |                  |                       | 90.00                              |
| 42     | "     | Sol. St'l | 22.25            | 24.00                 |                                    | 70        | "     | Steel     |                  |                       | 92.00                              |
| 42     | "     | S C. St'l | 24.25            | 26.00                 |                                    | 71        | "     | Chill     |                  |                       | 91.50                              |
| 107    | "     | Chill     | 17.50            | 19.25                 | 22.75                              | 71        | "     | Steel     |                  |                       | 93.50                              |
| 107    | "     | Steel     | 19.50            | 21.25                 | 24.75                              | 73        | "     | Chill     |                  |                       | 93.00                              |
|        |       |           |                  |                       |                                    | 73        | "     | Steel     |                  |                       | 95.00                              |
|        |       |           |                  |                       |                                    | 92        | "     | "         |                  |                       | 95.00                              |
|        |       |           |                  |                       |                                    | 93        | "     | "         |                  |                       | 98.00                              |

\*Prices Include Shifting Clevis.

|                                                                            |         |
|----------------------------------------------------------------------------|---------|
| For 3-horse Evener, not taken on 2-Way Sulky Plow, deduct net.....         | \$ 1 00 |
| For 2-horse Jointers or Colters, not taken on 2-Way Sulky, deduct net..... | 1 00    |
| For 2-horse Evener, taken instead of 3-horse, no deduction.....            |         |
| For 3-horse Evener, not taken on Single Sulky, deduct net.....             | 1 00    |
| For H-C or Jointer, not taken on Single Sulky, deduct net.....             | 50      |
| °New Series Wood Beam One-horse Reversible Plow.                           |         |

### LIST PRICES ON IMPLEMENTS.

|                                                                               |       |
|-------------------------------------------------------------------------------|-------|
| Le Roy Garden Plows.....                                                      | 5 50  |
| Le Roy 5-Tooth Cultivator, with lever and side braces and wheel.....          | 9 50  |
| Le Roy 5-Tooth Cultivator, with double lever, side braces and wheel.....      | 10 00 |
| Le Roy 14 Spike-tooth Cultivator, with lever, side braces and wheel.....      | 10 00 |
| No. 2 Shovel Plow.....                                                        | 9 50  |
| No. 10 Shovel Plow.....                                                       | 11 50 |
| No. 5 Hiller and Coverer.....                                                 | 14 00 |
| No. 6 Disc Hiller and Coverer.....                                            | 17 20 |
| 2-horse Walking Cultivator, 5-tooth.....                                      | 38 60 |
| 3-horse Walking Cultivator, 7-tooth.....                                      | 43 00 |
| 4-horse Walking Cultivator, 9-tooth.....                                      | 54 25 |
| 24-inch Steel Land Rollers, 3-section, 8-foot.....                            | 57 25 |
| 26-inch Steel Land Rollers, 3-section, 8-foot.....                            | 63 00 |
| No. 3 Marker.....                                                             | 14 00 |
| Miller Bean Harvesters and Boss Potato Diggers, prices quoted on application. |       |

### EXPLANATION.

|                                                                                    |    |
|------------------------------------------------------------------------------------|----|
| Jointer points marked 110 fit all 2 and 3-horse right-hand square standard Jointer | 25 |
| All Jointer Points marked 138 fit all Left-hand Plows .....                        | 25 |
| All Jointer Points marked 69 fit Nos. 30 and 40 Plows .....                        | 35 |
| All Jointer Points marked 44 fit Nos. 35 and 37 Plows .....                        | 30 |
| Jointer Moldboards marked 13 fit 2 and 3-horse right-hand square Standard Jointer. | 50 |
| Jointer Moldboards marked 139 fit all left-hand Plows .....                        | 50 |
| Jointer Moldboard (steel) No. 167 fit Nos. 30 and 40 Plows.....                    | 75 |
| Jointer Moldboards marked 47 fit Nos. 35 and 37 Plows.....                         | 50 |
| NOTE—Shoes are alike for 33, 34 and 35 Plows.                                      |    |
| Shoes are alike for 30, 31, 32, 40, 41 and 42 Plows.                               |    |
| Polished Shoes 15c extra.                                                          |    |
| No. 52 Saddle fits 33, 34 and 35 Plows.                                            |    |
| No. 45 Saddle fits 37 Plows.                                                       |    |
| No. 173 Saddle fits 30, 31 and 32 Plows.                                           |    |
| No. 530 Saddle fits 40, 41 and 42 Plows.                                           |    |
| No. 108, 50, 70R Standards interchange.                                            |    |
| No. 109, 72R Standards interchange.                                                |    |
| No. 110, 52, 73R and 93R Standards interchange.                                    |    |
| No. 508, 70L Standards interchange.                                                |    |
| No. 509, 71L, 72L, 73L, 93L and 510 Standards Interchange.                         |    |

For Prices on Other Repairs see Index on Page 16.

| Number | SHARES                  |        |      |       |        |               |       | MOLDBOARDS |                |                |      | Frogs<br>or<br>Sadd. | Bms. | Join'r<br>Mldbs |       |
|--------|-------------------------|--------|------|-------|--------|---------------|-------|------------|----------------|----------------|------|----------------------|------|-----------------|-------|
|        | Plain<br>Pitch<br>Stony | Colt'r | Slip | Steel | Join'r | Land-<br>side | Shoes | Chill      | Solid<br>Steel | S. C.<br>Steel | Shin |                      |      |                 | Stan. |
| 2½     | .80                     | .95    |      |       | .25    | .90           |       | 3.50       |                | 8.25           |      |                      |      | 4.00            |       |
| 4      | .90                     | 1.05   |      |       | .25    | 1.25          |       | 6.00       |                |                |      |                      |      | 5.00            | .50   |
| 6½     | .65                     |        |      |       | .25    | 1.00          |       | 3.50       |                |                |      | 3.00                 |      | 2.00            |       |
| 7      | .70                     | .85    |      |       | .25    | 1.10          |       | 3.50       |                |                |      | 3.50                 |      | 2.25            | .50   |
| 8      | .70                     | .85    |      |       | .25    | 1.10          |       | 4.00       |                |                |      | 3.50                 |      | 2.25            | .50   |
| 9      | .85                     | 1.00   | 1.05 |       | .25    | 1.50          |       | 5.00       |                | 7.75           | .75  | 4.00                 |      | 2.75            | .50   |
| 10     | .85                     | 1.00   | 1.05 |       | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.00                 |      | 2.75            | .50   |
| 12     | .90                     | 1.05   | 1.10 |       | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.25                 |      | 3.00            | .50   |
| 14     | .90                     | 1.05   | 1.10 |       | .25    | 1.50          |       | 6.00       |                | 8.25           | .75  | 4.25                 |      | 3.00            | .50   |
| 16     | .90                     |        |      |       |        |               | 1.00  | 4.25       |                |                |      | 3.50                 |      | 2.25            |       |
| 21     | .85                     | 1.00   | 1.05 |       | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  |                      |      | 5.25            | .50   |
| 22     | .90                     | 1.05   | 1.10 |       | .25    | 1.50          |       | 6.00       |                | 8.25           | .75  |                      |      | 5.25            | .50   |
| 30     | 1.10                    |        |      |       | .35    |               |       | 1.35       | 6.75           | 7.75           |      | 4.50                 | 2.00 | 5.00            | .75   |
| 31     | 1.10                    |        |      |       | .35    |               |       | 1.35       | 6.75           | 7.75           |      | 4.50                 | 2.00 | 5.00            | .75   |
| 32     | 1.10                    |        |      |       |        |               | 1.35  |            | 6.75           | 7.75           |      | 4.50                 | 2.00 | 5.00            |       |
| 33     | 1.10                    |        |      |       | .30    |               | 1.35  | 5.00       |                | 7.75           |      |                      | 2.00 | 4.75            | .50   |
| 34     | 1.10                    |        |      |       |        |               | 1.35  | 5.00       |                | 7.75           |      |                      | 2.00 | 4.75            |       |
| 35     | 1.10                    |        |      |       | .30    |               | 1.35  | 5.00       |                | 7.75           |      |                      | 2.00 | 7.00            | .50   |
| 37     | 1.10                    |        |      |       | .30    |               | 1.35  | 5.00       |                | 7.75           |      |                      | 2.00 | 5.50            | .50   |
| 40     | 1.00                    |        |      |       | .35    |               | 1.35  |            | 6.50           | 7.50           |      | 4.25                 | 2.00 | 5.00            | .75   |
| 41     | 1.00                    |        |      |       | .35    |               | 1.35  |            | 6.50           | 7.50           |      | 4.25                 | 2.00 | 5.00            | .75   |
| 42     | 1.00                    |        |      |       |        |               | 1.35  |            | 6.50           | 7.50           |      | 4.25                 | 2.00 | 5.00            |       |
| 107    | .65                     | .80    | .85  | 4.00  | .25    | .90           | .60   | 5.00       |                | 7.00           | .75  | 3.00                 |      | 5.50            | .50   |
| 108    | .75                     | .90    | .95  | 4.00  | .25    | 1.45          |       | 5.25       |                | 7.25           | .75  | 3.50                 |      | 6.50            | .50   |
| 109    | .85                     | 1.00   | 1.05 | 4.00  | .25    | 1.50          |       | 5.50       |                | 7.75           | .75  | 4.00                 |      | 6.50            | .50   |
| 110    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.00                 |      | 6.50            | .50   |
| 112    | .90                     | 1.05   | 1.10 | 4.25  | .25    | 1.60          |       | 6.00       |                | 8.25           | .75  | 4.25                 |      | 6.50            | .50   |
| 114    | .90                     | 1.05   | 1.10 | 4.25  | .25    | 1.60          |       | 6.00       |                | 8.25           | .75  | 4.25                 |      | 6.50            | .50   |
| 209    | .85                     | 1.00   | 1.05 | 4.00  | .25    | 2.00          | .75   |            | 6.75           | 7.75           |      | 4.00                 |      | 6.50            | .50   |
| 210    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 2.25          | .75   |            |                | 8.25           | .75  | 4.00                 |      | 6.50            | .50   |
| 508    | .75                     | .90    | .95  | 4.00  | .25    | 1.45          |       | 5.25       |                | 7.25           | .75  | 3.50                 |      | 6.50            | .50   |
| 509    | .85                     | 1.00   | 1.05 | 4.00  | .25    | 1.50          |       | 5.50       |                | 7.75           | .75  | 4.00                 |      | 6.50            | .50   |
| 510    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.00                 |      | 6.50            | .50   |
| 70R    | .75                     | .90    | .95  | 4.00  | .25    | 1.45          |       | 5.25       |                | 7.25           | .75  | 3.50                 |      | 8.00            | .50   |
| 71R    | .85                     | 1.00   | 1.05 | 4.00  | .25    | 1.50          |       | 5.50       |                | 7.75           | .75  | 4.00                 |      | 8.00            | .50   |
| 73R    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |
| 92R    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 2.00          | .75   |            |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |
| 93R    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 2.25          | .75   |            |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |
| 70L    | .75                     | .90    | .95  | 4.00  | .25    | 1.45          |       | 5.25       |                | 7.25           | .75  | 3.50                 |      | 8.00            | .50   |
| 71L    | .85                     | 1.00   | 1.05 | 4.00  | .25    | 1.50          |       | 5.50       |                | 7.75           | .75  | 4.00                 |      | 8.00            | .50   |
| 73L    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 1.50          |       | 5.50       |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |
| 92L    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 2.00          | .75   |            |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |
| 93L    | .85                     | 1.00   | 1.05 | 4.25  | .25    | 2.25          | .75   |            |                | 8.25           | .75  | 4.00                 |      | 8.00            | .50   |

Wide-cutting Cast Shares, plain, 108, 109,  
110, 71, 73, 508, 509, 510.....\$ 1 00

Wide-cutting Cast Shares, colter, 108, 109,  
110, 71, 73, 508, 509, 510.....1 15

Polished Landsides, extra.....15

Shares interchangeable (9-10), (30, 31, 32, 33,  
34, 35), (40, 41, 42), (70L, 508), (73L, 93L,  
510, 92L), (71L, 72L, 509), (92R, 209), (112,  
114), (110, 210, 73R, 93R), (109, 72R), (108,  
70R).

Slips, all numbers, each.....20

Polish Points, extra.....10

Alfalfa Points, extra.....10

## JOINTERS AND PARTS.

Jointers, complete, for all 1-H Plows, \$ 2 75  
Jointers, complete, for all 2 and 3-H  
Plows (except for 30 and 40).....3 50  
Jointers, complete, for 30 and 40 Plows  
(with spring).....4 00  
110 Jointers and Attachments, complete, fit  
all right Sulky Plows by using  
Bracket No. 246.....3 50  
Jointers, complete, less Attachments,  
for 1-horse Plows.....2 00  
Jointers, complete, less Attachments,  
for 2 and 3-horse Plows.....2 50  
7 Upper Jointer Standard with Bolts, 7  
and 8 Plows.....1 25  
4 Upper Jointer Standard, fits 4 and 6  
Plows.....1 25  
21 Upper Jointer Standard with Bolts, fit  
9, 10, 12, 14, 21 and 22 Plows.....1 50  
16 Lower Jointer Standard, complete, fits  
9, 10, 12, 14, 21 and 22 Plows.....1 75  
16 Lower Jointer Standard only, fits 9,  
10, 12, 14, 21 and 22 Plows.....1 25  
36 Lower Jointer Standard, complete, fits  
7 and 8 Plows.....1 75  
36 Lower Jointer Standard only, fits 7  
and 8 Plows.....1 25  
202 Jointer Support for 21 and 22 Plows...1 25  
78 Jointer Standard Guide Washer, 4 and  
6 Plows.....50  
122 Lower Section, complete, for 108, 109,  
110, 112 and 114 Plows.....1 75  
122 Lower Section only, for 108, 109, 110,  
112 and 114 Plows.....75  
77 Lower Section, complete, for 4 and 6  
Plows.....1 75  
77 Lower Section only, for 4 and 6 Plows75

137 Lower Section, complete, for 509 and  
510 Plows.....1 75  
137 Lower Section only, for 509 and 510  
Plows.....75  
140 Jointer Standard Bracket, 509 and 510  
Plows.....50  
29 Pipe Socket for Jointer, 35 and 37  
Plows.....75  
30 Lower Section Jointer, 35 and 37  
Plows.....75  
119 Jointer Standard Beam Washer.....15  
120 Jointer Standard Bracket, 108, 109,  
110, 112 and 114 Plows.....50  
121 Jointer Standard Eyebolt and Nut, 108,  
109, 110, 112, 114, 210, 509, 510.....50  
180 Main Jointer Standard (steel), 108, 109,  
110, 112 and R. H. Sulky Plow Bases1 50  
178 Jointer Standard (steel), 35 and 37  
Plows.....1 25  
179 Jointer Standard, 30, 31, 40, 41 Plows.1 25  
187 Main Jointer Standard (steel), 508,  
509, 510 and L. H. Sulky Plow Bases1 50  
152 Rear Spring Guide, 30 and 40 Plows..30  
162 Left Jointer Bracket, 30 and 40 Plows1 25  
163 Right Jointer Bracket, 30 and 40 Plows1 25  
164 Jointer Spring Guide, 30 and 40 Plows40  
165 Jointer Shift Casting, 30 and 40 Plows35  
166 Jointer Point (old style) 30 plows...30  
167 Jointer Moldboard, 30 and 40 Plows...75  
176 Jointer Socket, 30 and 40 Plows.....60  
69 Jointer Point and Lower Section for  
30 and 40 Plows.....35  
41 Jointer Point, 7 and 8 Plows.....25  
42 Jointer Moldboard, 7 and 8 Plows.....50  
43 Jointer Moldboard, 35 and 37 Plows...50  
44 Jointer Point for 35 and 37 Plows.....30

For Prices on Other Repairs see Index on Page 16.

## WHEELS AND PARTS.

|       |                                                                                   |         |
|-------|-----------------------------------------------------------------------------------|---------|
|       | Wheel and Standard with attachments, comp., one-horse .....                       | \$ 1 50 |
|       | Wheel and Axle, comp. ....                                                        | 1 10    |
|       | Wheel and Standard with attachments, comp., all other plows. ....                 | 1 75    |
| 1     | Wheel Standard Eyebolt, 9, 14, 21, 22, 30, 32, 108, 109, 110 plows—R. and L. .... | 40      |
| 6     | Wheel Standard Washer, 7, 8 plows. ....                                           | 15      |
| 12    | Back Wheel Washer on Standard. ....                                               | 15      |
| 17    | Washer on Eyebolt, Wood Bean plows. ....                                          | 15      |
| 18    | Wheel, 7" diameter .....                                                          | 60      |
| 27    | Wheel, 6½" diameter. ....                                                         | 60      |
| 34    | Wheel Axles, 7, 8 plow .....                                                      | 25      |
| 35    | Wheel Washer .....                                                                | 15      |
| K     | Wheel Standard Eyebolt, 33, 37 plows. ....                                        | 40      |
| X     | Wheel Standard Eyebolt, 7, 8 plows. ....                                          | 40      |
| 61    | Wheel Axles .....                                                                 | 25      |
| 66    | Wheel Standard Bracket, 6½ plow. ....                                             | 25      |
| 72-73 | Washer for 4 and 6 plows. ....                                                    | 10      |
| 74    | Wheel, 7" diameter, 4, 6 plows. ....                                              | 60      |
| 181   | Wheel Square Standard, (steel), all Le-Roy plows .....                            | 1 00    |
| 74    | Wheel and Axle and Bolt, 4 and 6 plows .....                                      | 1 10    |
| 76    | Wheel Standard, comp., 4 and 6 plows .....                                        | 1 25    |
| 113   | Wheel Standard for 2½ plow. ....                                                  | 85      |
| 126   | Wheel Standard Bracket, 108, 109, 110 and 112 plows. ....                         | 40      |
| 134   | Wheel Standard Bracket, 114 plow. ....                                            | 40      |
| 141   | Wheel Standard Bracket, 508, 509, 510 plows .....                                 | 40      |
| 507   | Wheel Standard Bracket, 50, 51, 52 plows .....                                    | 40      |
| 508   | Wheel Standard Plate, 50, 51, 52 plows. ....                                      | 35      |
| 509   | Wheel Axle, 6½, 50, 51, 52 plows. ....                                            | 25      |
| 510   | Wheel Standard, 6½, 50, 51, 52 plows. ....                                        | 1 00    |

## HANDLES.

|                                   | Single. | Pairs.  |
|-----------------------------------|---------|---------|
| One horse, fitted. ....           | \$ 65   | \$ 1 50 |
| Two and three horse, fitted. .... | 75      | 1 75    |
| Handle Rods, each. ....           | 15      |         |
| Handle Rounds, each. ....         | 15      |         |
| Handle in rough, one horse. ....  | 55      |         |
| Handle in rough, two-horse. ....  | 65      |         |
| Handle Braces, pair. ....         | 75      |         |
| Handle Braces, each. ....         | 40      |         |

## HANDLE ATTACHMENTS AND MOLD-BOARD BRACES.

|      |                                                                    |       |
|------|--------------------------------------------------------------------|-------|
| 8    | Moldboard Spreader, 7, 8 plow. ....                                | \$ 75 |
| 9    | Shift Piece for Handles, 7, 8 plows. ....                          | 35    |
| 10   | Handle Brace, 7, 8 plows. ....                                     | 75    |
| 11   | Handle Brace Washer, 7, 8 plows. ....                              | 15    |
| 20   | Beam Rest for Handles, 9, 10 plows. ....                           | 1 00  |
| 26   | Handle Support for 33, 34, 35, 37 plows .....                      | 1 00  |
| 31   | Clevis Rod Rest on Handles, 33, 35, 37 plows .....                 | 15    |
| 32   | Beam Rest for Handles, 12, 14 plows. ....                          | 1 00  |
| 59   | Main Moldboard Brace, 6½ plow. ....                                | 40    |
| 60   | Upper Moldboard Brace, 6½ plow. ....                               | 50    |
| 65   | Upper Handle Brace, 6½ plow. ....                                  | 60    |
| 68   | Lower Handle Brace, 6½ plow. ....                                  | 30    |
| 116  | Main Handle Support and Moldboard Brace, 110, 112, 114 plows. .... | 1 00  |
| 131  | Main Handle Support and Moldboard Brace, 108, 109 plows. ....      | 1 00  |
| 142  | Main Handle Support and Moldboard Brace, 509, 510 plows. ....      | 1 00  |
| 148  | Main Handle Support and Moldboard Brace, 209, 210 plows. ....      | 1 00  |
| 200  | Main Handle Support and Moldboard Brace, 21, 22 plows. ....        | 1 00  |
| 201  | Upper Right Moldboard Lug, 21, 22 plows .....                      | 50    |
| 203X | Lower Left Handle Support, 21 and 22 plows .....                   | 50    |
| 204X | Lower Right Handle Support and Moldboard Brace, 21, 22 plows. .... | 40    |
| 205  | Handle Support to Beam, 21, 22 plows. ....                         | 40    |
| 45   | Saddle for 37 plow. ....                                           | 1 50  |
| 46   | Moldboard Y-Brace, 30, 31, 32, 37 plow .....                       | 85    |
| 531  | Moldboard Y-Brace, 40, 41, 42 plows. ....                          | 75    |
| 48   | Hook Brace and Nut, 33, 34, 35, 37 plows .....                     | 35    |
| 52   | Saddle for 33, 34, 35 plows. ....                                  | 1 50  |
| 53   | Moldboard Y-Brace, 33, 34, 35 plows. ....                          | 85    |
| 47   | Washer for Handle Rest, 33, 34, 35, 37 plows .....                 | 10    |
|      | Moldboard Fillers, each. ....                                      | 25    |
|      | Double Eyebolts with Nuts, each. ....                              | 50    |
|      | 3-inch Rings .....                                                 | 15    |
|      | Staples, each .....                                                | 08    |

## HANDLE ATTACHMENTS AND MOLD-

## BOARD BRACES—Continued.

|     |                                                                           |      |
|-----|---------------------------------------------------------------------------|------|
| 81  | Right Handle Brace to Beam, 4, 6 plows .....                              | 50   |
| 82  | Left Handle Brace to Beam, 4, 6 plows .....                               | 50   |
| 83  | Right Handle Support for Cast Moldboard, 4, 6 plows. ....                 | 1 00 |
| 84  | Left Handle Support to Standard, 4 Premier and 5 Wilder. ....             | 1 00 |
| 85  | Right-hand Support for Steel Moldboard, 4, 6 plows. ....                  | 1 00 |
| 88  | Handle Brace Washer, 4, 6 plows. ....                                     | 10   |
| 117 | Lower Right Handle Support and Moldboard Brace, 110, 112, 114 plows. .... | 60   |
| 118 | Lower Left Handle Support and Moldboard Brace, 110, 112, 114 plows. ....  | 60   |
| 127 | Upper Right-hand Moldboard Lug, 110, 112, 114 plows. ....                 | 40   |
| 132 | Lower Right Handle Support and Moldboard Brace, 108, 109 plows. ....      | 50   |
| 133 | Lower Left Handle Support and Moldboard Brace, 108, 109 plows. ....       | 50   |
| 142 | Main Handle Rest and Moldboard Brace, 509, 510 plows. ....                | 1 00 |
| 143 | Lower Right-hand Handle Support and Moldboard Brace, 509, 510 plows. .... | 50   |
| 144 | Lower Left-hand Handle Support and Moldboard Brace, 509, 510 plows. ....  | 50   |
| 145 | Upper Left Handle Support and Moldboard Lug, 509, 510, plows. ....        | 40   |
| 160 | Main Standard and Handle Support, 30, 31 and 32 plows. ....               | 4 50 |
| 296 | Main Handle Support and Moldboard Brace, 209 plow. ....                   | 1 00 |
| 302 | Right Moldboard Lug, 209 plow. ....                                       | 40   |
| 303 | Lower Handle Support and Moldboard Brace, 209 plow. ....                  | 50   |
| 375 | Main Handle Support and Moldboard Brace, 508 plow. ....                   | 1 00 |
| 376 | R. H. Lower Handle Support and Moldboard Brace, 508 plow. ....            | 50   |
| 377 | L. H. Lower Handle Support and Moldboard Brace, 508 plow. ....            | 50   |

## MISCELLANEOUS.

|     |                                                        |       |
|-----|--------------------------------------------------------|-------|
|     | Twisted Link .....                                     | \$ 30 |
| 24  | L. H. Moldboard Catch, 33, 34, 35 and 37 plows .....   | 25    |
| 25  | R. H. Moldboard Catch, 33, 34, 35 and 37 plows .....   | 25    |
| 47  | Washer for Guide Plate N. ....                         | 15    |
| 49  | Moldboard Lock, 37 plow. ....                          | 75    |
| 51  | Guide Loop for 33, 34, Spring. ....                    | 30    |
| 54  | Moldboard Lock, 33, 34, 35 plows. ....                 | 75    |
| Y   | Guide Loop for 35, 37 Spring. ....                     | 30    |
| N   | Guide Washer for Spring, 33, 34, 35 and 37 plows. .... | 20    |
| 184 | Reverse Spring, 33, 34, 35, 37 plows. ....             | 1 50  |
| R   | Right Nut for Clevis Rod Screw. ....                   | 20    |
| L   | Left Nut for Clevis Rod Screw. ....                    | 20    |
| 87  | Beam Washer, 4-plow. ....                              | 10    |
| 128 | Beam Washer, 108, 109, 110, 112, 114 plows .....       | 10    |
| S   | Beam Washer .....                                      | 10    |
| P   | Wheel Standard Eyebolt Washer. ....                    | 10    |
| D   | Eyebolt Washer, 33, 35, 37 plows. ....                 | 10    |
|     | 37 Plow Wrench (malleable). ....                       | 25    |
|     | 37X Plow Wrench .....                                  | 25    |
| 147 | Landside Filler, 210 plow. ....                        | 50    |
| 154 | R. H. Catch, 30, 31, 32, 40, 41, 42 plows .....        | 30    |
| 155 | L. H. Catch, 30, 31, 32, 40, 41, 42 plows .....        | 30    |
| 156 | N. B. Lock, 30, 31, 32, 40, 41, 42 plows .....         | 75    |
| 157 | Catch Support, 30, 31, 32, 40, 41, 42 plows .....      | 75    |
| 158 | Catch Spring Cap, 30, 31, 32, 40, 41, 42 plows .....   | 15    |
| 159 | Latch Spring, 30, 31, 32, 40, 41, 42 plows .....       | 30    |
| 160 | Main Standard, 30, 31, 32 plows. ....                  | 4 50  |
| 161 | Shift Spring, 30, 40 plows. ....                       | 1 00  |
| 168 | Beam Cap, 30, 31, 40, 41 plows. ....                   | 85    |
| 169 | Beam Cap, 32, 42 plows. ....                           | 60    |
| 173 | Saddle, 30, 31, 32 plows. ....                         | 1 50  |
| 175 | Inner Shoe, 30, 31, 32, 40, 41, 42 plows .....         | 1 50  |

For Prices on Other Repairs see Index on Page 16.

# REPAIRS FOR LE ROY PLOWS, WALKING AND SULKY.

5

## PARTS FOR ROLLING COLTER.

|     |                                                       |       |
|-----|-------------------------------------------------------|-------|
| 316 | Box (2 pieces) each.....                              | \$ 20 |
| 317 | Bearing (2 pieces) each.....                          | 20    |
| 318 | Hub .....                                             | 50    |
| 319 | Castor .....                                          | 1 25  |
| 320 | Steel Standard .....                                  | 1 00  |
| 321 | Beam Bracket .....                                    | 60    |
|     | Beam Bracket Plate.....                               | 30    |
| 322 | Wedge Washer .....                                    | 20    |
|     | 12" Rolling Colter Blade and Hub.....                 | 2 50  |
|     | 13" Rolling Colter Blade and Hub.....                 | 2 50  |
|     | 12" Rolling Colter, comp. with attach-<br>ments ..... | 5 00  |
|     | 13" Rolling Colter, comp. with attach-<br>ments ..... | 5 25  |

## COLTERS AND PARTS.

|     |                                                                                                     |         |
|-----|-----------------------------------------------------------------------------------------------------|---------|
|     | Colter, comp. with attachments, 30 and<br>40 plows .....                                            | \$ 4 00 |
|     | Colters, complete, for all 1-horse plows                                                            | 2 50    |
|     | Colters, complete, for all 2 and 3-horse<br>plows and sulkies (except No. 30 and<br>40 plows) ..... | 3 50    |
|     | Colters, less attachments, for 2 and 3-<br>horse plows .....                                        | 2 50    |
|     | Colters, less attachments, for 1-horse<br>plows .....                                               | 1 75    |
| 28  | Dog for 35 and 37 plows.....                                                                        | 40      |
| 119 | Colter Beam Washer.....                                                                             | 15      |
| 120 | Colter Bracket, 110, 112, 114 plows....                                                             | 50      |
| 121 | Eyebolt and Nut, 108, 109, 110, 112, 114,<br>210, 509, 519 plows and Sulky.....                     | 50      |
| 326 | Under Washer for Coil Spring Colter<br>attachment, 30, 40 plows.....                                | 20      |
| 327 | Upper Washer for Coil Spring attach-<br>ment, 30, 40 plows.....                                     | 20      |
| 328 | Right Bracket Colter Attachment, 30,<br>40 plows .....                                              | 75      |
| 329 | Left Bracket Colter Attachment, 30,<br>40 plows .....                                               | 75      |
| 330 | Shift Wedge Colter Attachment, 30,<br>40 plows .....                                                | 35      |
| 331 | Front Shift Arm Colter Attachment,<br>30, 40 plows .....                                            | 40      |
| 332 | Rear Shift Arm Colter Attachment,<br>30, 40 plows .....                                             | 40      |

## CLEVISES AND PARTS.

|     |                                                                              |    |
|-----|------------------------------------------------------------------------------|----|
| 0   | Small Front Clevis with Pin, 7, 8 plows                                      | 15 |
| 2   | Small Front Clevis with Pin, all Steel<br>Beam plows .....                   | 20 |
| 3   | Head Cross Clevis, comp. with Pin, 7,<br>8 plows .....                       | 50 |
|     | Cross Clevis Pin.....                                                        | 10 |
| 4   | Right-hand Clevis Jaw, 7, 8 plows.....                                       | 30 |
| 5   | Left-hand Clevis Jaw, 7, 8 plows.....                                        | 60 |
| 5X  | Left-hand Clevis, less Bracket.....                                          | 30 |
| 14  | Head Cross Clevis, comp. with Pin, 9,<br>10, 12, 14 plows (no shackles)..... | 65 |
| 15  | R. H. Clevis Jaw, 9, 10, 12, 14 plows..                                      | 40 |
| 19  | L. H. Clevis Jaw, 9, 10, 12, 14 plows..                                      | 75 |
| 22  | Bearing for Clevis Rod, 35, 37 plows..                                       | 20 |
| 23  | Clip Bolt for Clevis Rod, 35, 37 plows.                                      | 15 |
| H   | Coupling Joint for Clevis Rod, 33, 35,<br>37 plows .....                     | 25 |
| 33  | Front Socket Rest Clevis Rod, 33, 35,<br>37 plows .....                      | 45 |
| 38  | Clevis Hook, 30, 31, 32, 33, 34, 35, 37,<br>40, 41, 42 plows.....            | 35 |
| 39  | Head Clevis, 33, 34, 35, 37 plows.....                                       | 60 |
| 50  | Head Clevis, 32, 34 plows.....                                               | 45 |
| 62  | Right Clevis Jaw, 6 1/2 plow.....                                            | 20 |
| 63  | Left Clevis Jaw, 6 1/2 plow.....                                             | 45 |
| 75  | Head Clevis, 4, 6 Steel Beam plows....                                       | 85 |
| 206 | R. H. Clevis Side, 21, 22 plows.....                                         | 30 |
| 207 | L. H. Clevis Side, 21, 22 plows.....                                         | 30 |
| 208 | Head Cross Clevis, 21, 22 plows.....                                         | 30 |
| 40  | Clevis Rod Screw, 30, 31, 33, 35, 37<br>plows .....                          | 60 |

## CLEVISES AND PARTS—Continued.

|     |                                                                      |      |
|-----|----------------------------------------------------------------------|------|
| 211 | 3-horse Clevis for 21, 22 plows, com-<br>plete with Rod.....         | 1 50 |
|     | Clevis Pins, small.....                                              | 05   |
|     | Clevis Pins, large.....                                              | 10   |
|     | Clevis Rings .....                                                   | 10   |
|     | Clevis Adjusting Rod, handle section<br>steel, 33, 35, 37 plows..... | 75   |
|     | Clevis Adjusting Rod Beam Section,<br>33, 35, 37 plows.....          | 75   |
| 112 | Main Clevis, 2 1/2 plow.....                                         | 50   |
| 123 | Beam Cap, 108, 109, 110, 112, 114, 509,<br>510, 209, 210 plows.....  | 50   |
| 124 | Main Clevis with Bolt, 5-hole, 108 plow                              | 65   |
| 125 | Main Clevis with Bolt, 10-hole, 110, 112,<br>210 plows .....         | 1 00 |
| 129 | Main Clevis with Bolt, 7-hole 109, 114,<br>209 plows .....           | 75   |
| 150 | Main Clevis with Bolt, 10-hole, 509, 510<br>plows .....              | 1 00 |
| 170 | Clip Bolt and Nut for Clevis Rod, 30,<br>31, 40, 41 plows.....       | 25   |
| 171 | Beam Section Clevis Rod, 30, 31, 40, 41<br>plows .....               | 75   |
| 172 | Handle Section Clevis Rod, 30, 31, 40,<br>41 plows .....             | 75   |
| 177 | Clip Bearing for Shifting Rod, 30, 31,<br>40, 41 plows.....          | 15   |
| 513 | Main Clevis with Bolt, 9-hole for 107<br>plows .....                 | 85   |
| 514 | Chain and Clevis, comp. for Vineyard<br>107 plows .....              | 1 50 |

## EXTRAS FOR LE ROY SULKY PLOWS.

|           |                                                     |      |
|-----------|-----------------------------------------------------|------|
| L.P. 5 R. | Wheel Cap, left side.....                           | 50   |
| L.P. 5 L. | Wheel Cap, right side.....                          | 50   |
| 215       | Pole Bracket to Frame.....                          | 50   |
| 220X      | Pole Shift Plate on Yoke, right seat...             | 35   |
| 224       | Pole Shift Coil Spring.....                         | 15   |
| 227       | Steel Frame, 2 x 1 1/2.....                         | 5 00 |
| 228       | Steel Frame Cross Brace, 3/4-round....              | 75   |
| 230       | Clevis, 3-hole .....                                | 60   |
| 231       | Swivel Clevis Part.....                             | 35   |
| 232       | Steel Eyebolt Swivel Clevis.....                    | 35   |
| 233       | Steel Draw Rod.....                                 | 1 00 |
| 234       | Steel Draw Ring.....                                | 50   |
| 235       | Draw Rod End.....                                   | 10   |
| 237       | Steel Seat Spring.....                              | 2 50 |
| 238       | R. H. Main Lever, comp.....                         | 5 00 |
| 238       | R. H. Main Lever only.....                          | 3 50 |
| 239       | R. H. Lever, upper latch.....                       | 35   |
| 240       | R. H. Lever, lower latch.....                       | 35   |
| 242       | R. H. Guide on Circle.....                          | 25   |
| 243       | Steel Coil Spring, main lever.....                  | 30   |
| 244XR     | R. H. Lever Circle.....                             | 1 25 |
| 245       | Right and Left-hand Lever Circle<br>Washer .....    | 10   |
| 246       | Right Jointer Bracket.....                          | 50   |
| 247       | Right Axle Clamp, upper.....                        | 35   |
| 248       | Right Axle Clamp, lower.....                        | 35   |
| 249       | Upper Right and Left Beam Bracket..                 | 1 00 |
| 250       | Lower Right and Left Beam Bracket..                 | 1 00 |
| 251       | Left-hand Axle Box.....                             | 25   |
| 252       | Pole Plate for Bracket 215.....                     | 50   |
| 253X      | Left-hand Main Lever, comp.....                     | 5 00 |
| 253X      | Left-hand Main Lever only.....                      | 3 50 |
| 254       | Left-hand Lever, upper latch.....                   | 35   |
| 255       | Left-hand Lever, lower latch.....                   | 35   |
| 257       | Left-hand Guide on Circle.....                      | 25   |
| 258X      | Left-hand Lever Circle, Single Sulky,<br>only ..... | 1 25 |
| 259       | Left-hand Jointer Bracket.....                      | 50   |
| 260       | Steel Right Main Axle.....                          | 3 00 |
| 261       | Steel Left Main Axle.....                           | 3 00 |
| 262       | Wheel Washer .....                                  | 15   |
|           | V-Brace to Cross Brace and Bolts....                | 40   |

For Prices on Other Repairs see Index on Page 16.

# REPAIRS FOR SULKY PLOWS AND OTHER IMPLEMENTS.

## SULKY PLOW EXTRAS—Continued.

|      |                                                                    |      |
|------|--------------------------------------------------------------------|------|
| 263  | Right Wheel Ratchet.....                                           | 75   |
| 264  | Left Wheel Ratchet.....                                            | 75   |
| 265  | Left Arm to Axle.....                                              | 85   |
| 266  | Left Arm to Axle Cap.....                                          | 40   |
| 276  | Right Arm to Axle.....                                             | 85   |
|      | Steel Pin, Lever and Axle Bracket....                              | 50   |
| 281  | Axle Bearing Washer on Beam.....                                   | 10   |
| 282  | Jointer Bearing Washer on Beam.....                                | 10   |
| 283  | Lower Lever Latch Washer Bearing....                               | 10   |
| 304  | Singletree End Loop.....                                           | 20   |
| 305  | Clevis and Ring (large).....                                       | 35   |
| 306  | Clevis and Ring (small).....                                       | 30   |
| 307  | Clevis, medium for hitch.....                                      | 30   |
| 308  | Clevis, large for hitch.....                                       | 35   |
| 309  | Twisted Links.....                                                 | 30   |
| 310  | Foot Rest.....                                                     | 50   |
| 311  | Singletree Hooks (right).....                                      | 30   |
| 312  | Singletree Hooks (left).....                                       | 30   |
| 313  | Large Evener Clevis.....                                           | 35   |
| 314  | Large Evener Clevis.....                                           | 35   |
| 321  | Standard Beam Bracket, R. and L. for all Sulkies.....              | 60   |
| 333  | Center Bearing for Foot Trip Shaft....                             | 30   |
| 334  | Foot Trip Castings.....                                            | 35   |
| 335  | Foot Trip Cam, New No. 361.....                                    | 30   |
| 336  | Foot Trip Lever, New No. 362.....                                  | 35   |
| 337  | Foot Trip Shaft, right (steel).....                                | 50   |
| 338  | Foot Trip Shaft, left (steel).....                                 | 50   |
| 339  | Foot Trip Shaft to Cam Lever (steel)....                           | 35   |
| 340  | Pole Shift Plate on Yoke, New No. 363                              | 50   |
| 341  | Pole End Shift Sector.....                                         | 85   |
| 342  | Pole Shift Front Sector.....                                       | 85   |
| 343  | Pole Shift Lever.....                                              | 1 25 |
| 344  | Pole Shift Lever Latch.....                                        | 15   |
| 345  | Pole Shift Lever Plunger.....                                      | 15   |
| 346  | Pole Shift Lever to End Sector (steel)....                         | 20   |
| 347  | Pole End Plate.....                                                | 50   |
| 348  | Seat Spring Tilt Lever, comp.....                                  | 1 50 |
| 349  | Seat Spring Tilt Catch.....                                        | 50   |
| 350  | Seat Spring Tilt Base and Sector.....                              | 1 50 |
| 351  | Main Lever Plunger (right).....                                    | 1 00 |
| 352  | Main Lever Plunger (left).....                                     | 1 00 |
| 353  | Main Wheel Axle Washer Key.....                                    | 10   |
| 354  | Left Yoke Bracket.....                                             | 1 75 |
| 355  | Right Yoke Bracket.....                                            | 1 75 |
| 356  | Center Axle Bearing on Yoke.....                                   | 1 75 |
| 357  | Foot Trip Shaft to Cam.....                                        | 40   |
| 358  | Steel Center Brace.....                                            | 1 00 |
| 359  | Seat Base for Stationary Seat.....                                 | 50   |
| 360  | Singletree U-Bolt.....                                             | 30   |
| 361  | Foot Trip Cam.....                                                 | 50   |
| 362  | Foot Trip Lever.....                                               | 50   |
| 363  | Pole Shift Plate on Yoke.....                                      | 1 00 |
| 364  | Pole Spreader and Tool Box.....                                    | 1 25 |
|      | Main Steel Wheel, each.....                                        | 6 00 |
|      | 2-horse Hitch, complete.....                                       | 4 50 |
|      | 3-horse Hitch, complete.....                                       | 5 50 |
|      | Whiffletrees, each.....                                            | 75   |
|      | Evener Bar (long).....                                             | 1 50 |
|      | Equalizer Bar.....                                                 | 1 00 |
|      | Sulky Pole.....                                                    | 2 50 |
|      | Sulky Seat.....                                                    | 1 00 |
|      | Sulky Neckyoke.....                                                | 1 25 |
|      | Stub Pole.....                                                     | 1 25 |
| 369  | Right Landside Filler, 93 Sulky.....                               | 50   |
| 370  | Left Landside Filler, 93 Sulky.....                                | 50   |
| 371  | Right Lower M. B. Lug, all right Sulky plow bases.....             | 30   |
| 372  | Lower M. B. Brace, all right Sulky plow bases.....                 | 40   |
| 373  | Left Lower M. B. Lug, all left Sulky plow bases.....               | 30   |
| 374  | Lower M. B. Brace, all left Sulky plow bases.....                  | 40   |
| 378  | Moldboard and Landside Brace, all right-hand Sulky plow bases..... | 60   |
| 379  | Upper M. B. Lug, all right-hand Sulky plow bases.....              | 30   |
| 380  | Moldboard and Landside Brace, all left-hand Sulky plow bases.....  | 60   |
| 381  | Upper M. B. Lug, all left-hand Sulky plow bases.....               | 30   |
| 383  | 5-hole Clevis.....                                                 | 75   |
| 384  | Pole End Shift Cam.....                                            | 1 00 |
| 385  | Pole End Shift Plate.....                                          | 1 00 |
| 391  | Stationary Seat Spring for single or reversible Sulky plows.....   | 1 50 |
| 392  | Right Weed Hook, complete.....                                     | 1 50 |
| 393  | Left Weed Hook, complete.....                                      | 1 50 |
| 394  | Weed Hook Clamp, right or left.....                                | 50   |
| 395  | Weed Hook U-Bolt, right or left.....                               | 30   |
| 396R | Removable Box (1917 Sulky Wheel)....                               | 1 00 |
| 396L | Removable Box (1917 Sulky Wheel)....                               | 1 00 |

## NO. 10 SHOVEL PLOW PARTS.

|      |                            |       |
|------|----------------------------|-------|
| 1-D  | Thumb Nut.....             | \$ 10 |
| 1-S  | Iron Standard.....         | 2 00  |
| 2-S  | Handle Rest.....           | 85    |
| 3-S  | Left Wheel Standard.....   | 75    |
| 4-S  | Right Wheel Standard.....  | 75    |
| 8-S  | Wing Spreader Hook.....    | 10    |
| 13-C | Wheel.....                 | 70    |
| 15-C | With Link.....             | 30    |
|      | Wood Beam.....             | 2 00  |
|      | Handles, each.....         | 65    |
|      | Points, each.....          | 75    |
|      | Handles, pairs.....        | 1 30  |
|      | Front Piece.....           | 1 25  |
| 10   | Wings, right and left..... | 1 00  |
| 10-S | Wing Spreader, pairs.....  | 60    |
|      | Hinges, per pair.....      | 20    |
| 17-S | Center Brace.....          | 40    |
|      | Bottom, complete.....      | 4 00  |

## NO. 2 SHOVEL PLOW PARTS.

|                       |       |
|-----------------------|-------|
| Wings, each.....      | \$ 75 |
| Clevis and Pin.....   | 60    |
| Bottom, complete..... | 3 25  |

NOTICE—All other parts same as No. 10 Extras.

## No. 5 and 6 HILLER PARTS . No. 6 No. 5

|                                    |       |
|------------------------------------|-------|
| Draw Rod, right and left, each..\$ | \$ 35 |
| 5-H Draw Iron.....                 | 40    |
| 12-H Right-hand Standard.....      | 2 00  |
| 13-H Left-hand Standard.....       | 2 00  |
| 38-H Adjusting Clamp, R or L.....  | 75    |
| 19-H Handle Bracket.....           | 75    |
| 20-H Pole Washer.....              | 10    |
| 21-H Handle Bracket Washer.....    | 10    |
| 22-H Right Pole Bracket.....       | 1 00  |
| 23-H Left Pole Bracket.....        | 1 00  |
| 24-H Shift Dog.....                | 25    |
| L. H. Moldboard.....               | 2 50  |
| R. H. Moldboard.....               | 2 50  |
| Cast Points, each.....             | 50    |
| Steel Points, each.....            | 50    |
| Pole.....                          | 2 00  |
| Frame Board.....                   | 1 00  |
| Handles, each.....                 | 65    |
| Handles, per pair.....             | 1 50  |
| 31-H 20" Disc, R or L, each.....   | 2 50  |
| 32-H Main Standard.....            | 2 00  |
| 33-H Axle.....                     | 50    |
| 34-H Disc Washer.....              | 15    |
| 35-H Axle Washer.....              | 10    |
| 36-H Moldboard Axle, R.....        | 75    |
| 37-H Moldboard Axle, L.....        | 75    |
| Axle Bolt.....                     | 25    |
| Steel Hiller Clips (set of 4)..... | 25    |

## NO. 3 MARKER PARTS.

|      |                                    |       |
|------|------------------------------------|-------|
| 1-M  | R. Right Handle Bracket.....       | \$ 50 |
| 2-M  | S. Left Handle Bracket.....        | 50    |
| 3-M  | Upper Shank Standard.....          | 70    |
| 4-M  | Lower Shank Standard.....          | 80    |
| 5-M  | Center Top Clamp.....              | 50    |
| 6-M  | End Top Clamp.....                 | 50    |
| 7-M  | Marker Plate.....                  | 50    |
| 8-M  | Spool.....                         | 25    |
|      | Beam.....                          | 2 00  |
|      | Thills, each.....                  | 1 25  |
|      | Thills, per pair.....              | 2 50  |
|      | Handles, each.....                 | 50    |
|      | Handle Brace.....                  | 70    |
|      | Guide Stick.....                   | 60    |
|      | Marker Point and Bolt, 5-inch..... | 50    |
|      | Marker Point and Bolt, 8-inch..... | 70    |
| 15-C | Hitch Hook and Link.....           | 30    |
| 9-M  | Upper Thill Brace.....             | 35    |
| 10-M | Lower Thill Brace.....             | 35    |
| 11-M | Draw Loop.....                     | 25    |
| 12-M | Clamp for Marker.....              | 10    |
| 13-M | Marker for Guide Stick.....        | 1 50  |

## ROLLER PARTS.

|     |                                       |       |
|-----|---------------------------------------|-------|
|     | Wood Bearing for Shaft (2 pieces).... | \$ 25 |
| 78  | Pole End.....                         | 75    |
|     | Steel Brackets, each.....             | 3 00  |
|     | Shaft.....                            | 7 50  |
| 7-R | Head Box.....                         | 60    |
| 8-R | Shaft Washer.....                     | 20    |
|     | Frame, complete.....                  | 15 00 |
|     | Seat.....                             | 1 00  |
|     | Roller Pole.....                      | 2 50  |
|     | Pole Braces, each.....                | 50    |
|     | Seat Spring.....                      | 1 25  |

For Prices on Other Repairs see Index on Page 16.

## MILLER BEAN HARVESTER PARTS.

|                                                   |         |
|---------------------------------------------------|---------|
| 50 Cast Drive Wheel (old and new machines) .....  | \$ 4 00 |
| 51 R. H. Lever .....                              | 3 00    |
| 52 L. H. Lever .....                              | 3 00    |
| 57 R. H. Divider .....                            | 1 75    |
| 58 L. H. Divider .....                            | 1 75    |
| 59 Lever Circle .....                             | 1 25    |
| 59-L N. S. Circle .....                           | 1 25    |
| 59-R N. S. Circle .....                           | 1 25    |
| 60 R. H. Steel Share and bolts.....               | 2 50    |
| 61 L. H. Steel Share and bolts.....               | 2 50    |
| 62 Divider Rod .....                              | 1 50    |
| 63 Front Beam (wood) .....                        | 75      |
| 64 Back Beam (wood) .....                         | 75      |
| 65 Small Wheel .....                              | 75      |
| 66 R. H. Guard (Cast Wheel) .....                 | 1 00    |
| 67 L. H. Guard (Cast Wheel) .....                 | 1 00    |
| 68 Small Axle .....                               | 25      |
| 69 Seat .....                                     | 1 00    |
| 70 Seat Spring .....                              | 1 25    |
| 71 Back End Pole Bracket .....                    | 1 50    |
| 72 R. H. Front Pole Bracket .....                 | 1 00    |
| 73 L.H. Front Pole Bracket .....                  | 1 00    |
| 74 Sway and Tilt Casting .....                    | 1 25    |
| 76 Tilt Lever complete .....                      | 1 50    |
| 77 Pole .....                                     | 3 00    |
| 78 Pole Iron .....                                | 75      |
| 79 Divider Bar Extension .....                    | 75      |
| 80 Sway Hitch-On Beam .....                       | 75      |
| 81 Sway Lever Catch .....                         | 60      |
| 83 Draft Rod .....                                | 60      |
| 84 Draft Bracket .....                            | 50      |
| 85 Lever Grip .....                               | 25      |
| 86 Lever Plunger .....                            | 30      |
| 88 Neckyoke with loop and eye-bolt complete ..... | 1 00    |
| 89 Evener .....                                   | 1 00    |
| 90 Small Axle Washer .....                        | 15      |
| 91 Main Lever Washer .....                        | 20      |
| 92 Small Spring .....                             | 10      |
| 93 Lever Chain .....                              | 35      |
| 94 Divider Bar Washer .....                       | 25      |
| 95 Divider Rod Washer .....                       | 25      |
| 97 Main Wheel Axle .....                          | 1 00    |
| 98 Wrench .....                                   | 25      |
| 99 Plunger Springs .....                          | 10      |
| 100 Spring Plate for Lever .....                  | 20      |
| 102-B Sway Lever Catch .....                      | 60      |
| 103-B Sway Lever complete .....                   | 1 50    |
| 104-B R. H. Guard for Steel Wheel.....            | 1 00    |
| 105-B L. H. Guard for Steel Wheel .....           | 1 00    |
| 106-B Divider Bar Washer .....                    | 25      |
| 107 Main Wheel Washer .....                       | 20      |
| 108 Lever Rod to Plunger .....                    | 15      |
| 109-B Main Wheel, Steel .....                     | 4 50    |
| 110-B Frame R. or L. .....                        | 2 50    |
| 111-B Shank R.H. .....                            | 4 00    |
| 112-B Shank L.H. .....                            | 4 00    |
| 134-A Box and Nut for steel wheel.....            | 1 00    |
| A Sway and Tilt Washer .....                      | 15      |
| Dividers complete Right and Left .....            | 12 50   |
| Lever complete with axle, each.....               | 4 50    |
| Pole complete with all castings.....              | 10 00   |

## CULTIVATOR PARTS.

|                                                                 |         |
|-----------------------------------------------------------------|---------|
| 9-C Center Beam Cap .....                                       | \$ 25   |
| 10-C Shank Interchange with old style .....                     | 1 50    |
| 11-C Circle Right and Left .....                                | 1 00    |
| 12-C Wedge for No. 11 Circle .....                              | 20      |
| 14-C Pole Bracket .....                                         | 25      |
| 50 Wheel .....                                                  | 4 00    |
| 51 Main Lever Left .....                                        | 3 00    |
| 52 Main Lever Right .....                                       | 3 00    |
| 78 Neckyoke Hook .....                                          | 75      |
| 86 Plunger on Main Lever .....                                  | 30      |
| 91-B Washer for Lever Circle .....                              | 20      |
| 97 Main Wheel Axle .....                                        | 1 00    |
| 107-B Quadrant Wheel Washer .....                               | 20      |
| 1-C Shank for 1-horse Cultivator.....                           | 75      |
| HX Washer for Pole Bracket .....                                | \$ 10   |
| 85 Latch on Main Lever .....                                    | 25      |
| 16-C Draw Rod .....                                             | 30      |
| 99-B Lever Plunger Spring .....                                 | 10      |
| 100-B Plunger or Loop .....                                     | 20      |
| 108-P Lever Rod to Plunger .....                                | 15      |
| Points, diamond, oval or sweeps, to fit old and new Shank ..... | 50      |
| 17-C Pole .....                                                 | \$ 3 00 |
| 18-C End Beam 2 3/4 x 3 inches .....                            | 1 00    |
| 19-C Center Beam 2 3/4 x 3 1/2 inches....                       | 1 00    |
| 20-C Front Beam 2 x 4 inches .....                              | 1 50    |
| 21-C Rear Beam 2 x 4 inches .....                               | 1 50    |
| 22-C Frame Braces 1 1/2 and 6 1/2 .....                         | 1 25    |

## EXTRAS FOR STEEL FRAME CULTIVATOR AND GARDEN PLOW.

|                                 |       |
|---------------------------------|-------|
| R. Cultivator Shank .....       | \$ 50 |
| L. Cultivator Shank .....       | 50    |
| Handles, pair .....             | 1 30  |
| Handles, each .....             | 65    |
| Handles Braces .....            | 25    |
| Rake .....                      | 35    |
| 4" Oval Cultivator Points ..... | 30    |
| Garden Plow Moldboard .....     | 60    |

| Blades           |       | Sweeps and Bolts |       |
|------------------|-------|------------------|-------|
| 2-inch .....     | \$ 15 | 6-inch .....     | \$ 30 |
| 2 1/2-inch ..... | 18    | 8-inch .....     | 40    |
| 3-inch .....     | 22    |                  |       |

|                                      |         |
|--------------------------------------|---------|
| Horse Hoes, set of three pieces..... | \$ 1 25 |
| Front or gauge wheel (each) .....    | 75      |
| 3 blade Shovel for Garden Plow.....  | 75      |

## BOLTS.

|                                                            |       |
|------------------------------------------------------------|-------|
| Main Standard Bolts, Wood Beam Plows .....                 | \$ 15 |
| Machine and Carriage Bolts under 5" (except special) ..... | 05    |
| Machine and Carriage Bolts over 5" (except special) .....  | 06    |
| All Plow Bolts .....                                       | 06    |
| Assorted Boxes, 50 Plow Bolts.....                         | 2 75  |
| Set Screws for Plows (all sizes).....                      | 08    |
| Cap Screws for Plows (all sizes).....                      | 08    |


## FOR 1914 STEEL FRAME MACHINE.

All parts interchange except as follows:

|                                  |         |
|----------------------------------|---------|
| NO.                              |         |
| 115-B Right Hand Shank .....     | \$ 4 50 |
| 116-B Left Hand Shank .....      | 4 50    |
| 117-B Right Hand Lever .....     | 3 00    |
| 118-B Left Hand Lever .....      | 3 00    |
| 119-B Circle Right or Left ..... | 1 25    |


|                                                            |    |
|------------------------------------------------------------|----|
| NO.                                                        |    |
| 120-B Sway Hitch on Beam.....                              | 75 |
| Bolts for Steel Shares .....                               | 06 |
| Machine and Carriage Bolts under 5" (except special) ..... | 05 |
| Machine and Carriage Bolts over 5" (except special) .....  | 07 |

For Prices on Other Repairs see Index on Page 16.




PARTS FOR LOVEJOY REVERSIBLE SULKY PLOW.

For Prices on Other Repairs see Index on Page 16.




PARTS FOR NOS. 29 AND 29X CAMBRIDGE PLOWS.


For Prices on Other Repairs see Index on Page 16.



PARTS FOR NOS. 26 AND 27 CAMBRIDGE PLOWS.



PARTS FOR NOS. 1-2, 38-39 AND 40 CAMBRIDGE PLOWS.



PARTS FOR COLTERS AND JOINTERS.

| Number | Beam  | Moldboard | With Clevis Only | With Wheel and Clevis | Full Rigged with Colter or Joinder | Number    | Beam  | Moldboard | With Clevis Only | With Wheel and Clevis | Full Rigged with Colter or Joinder |
|--------|-------|-----------|------------------|-----------------------|------------------------------------|-----------|-------|-----------|------------------|-----------------------|------------------------------------|
| 11     | Steel | Chill     | 20.00            | 21.75                 | 25.25                              | 29        | Steel | Sol.St'l  |                  |                       | 30.50                              |
| 11     | "     | S.C.St'l  | 22.00            | 23.75                 | 27.25                              | 29        | "     | S.C.St'l  |                  |                       | 33.00                              |
| 12     | "     | Chill     | 21.00            | 22.75                 | 26.25                              | 29X       | "     | Sol.St'l  |                  |                       | 31.50                              |
| 12     | "     | S.C.St'l  | 23.00            | 24.75                 | 28.25                              | 29X       | "     | S.C.St'l  |                  |                       | 34.00                              |
| 16C    | Wood  | Chill     | 12.50            | 14.00                 |                                    | 52        | "     | "         | 22.00            |                       |                                    |
| 26     | Steel | S.C.St'l  | 20.00            | 21.75                 | 25.25                              | 2-W. Sul. |       |           |                  |                       |                                    |
| 27     | "     | "         | 21.00            | 22.75                 | 26.25                              | 38-60     | Steel | S.C.St'l  |                  |                       | 125.00                             |
|        |       |           |                  |                       |                                    | 39-61     | Steel | S.C.St'l  |                  |                       | 128.00                             |

For 3-horse Evener not taken on 2-way Sulky Plow, deduct net .....\$ 1 00

For 2-horse Jointers or Colters not taken on 2-way Sulky, deduct net... 1 00

For 2-H Evener taken instead of 3-H, no deduction.

For 3-H Evener not taken on Single Sulky, deduct net ..... 1 00

For H-C or Joinder not taken on Single Sulky, deduct net ..... 50

All parts of the No. 38 and No. 39 Sulky Plows are interchangeable, with the exception of the boards and points.

All parts of the No. 29 and 29X Plows are the same, with the exception of the boards and points.

All parts of the No. 26 and 27 Plows are interchangeable, with the exception of the boards and points.

All parts of the No. 11 and 12 Plows are interchangeable, with the exception of boards, points and landsides.

#### REPAIR PARTS

##### FOR THE CAMBRIDGE MARKER.

|                                  |       |
|----------------------------------|-------|
| Marker Fingers .....             | \$ 25 |
| Marking iron .....               | 50    |
| Marking iron clip .....          | 15    |
| Seat, complete .....             | 3 50  |
| Pole, adjusting irons, each..... | 50    |
| Marker thimbles .....            | 30    |
| Hammer strap .....               | 30    |
| Marker Pole .....                | 2 50  |
| Handles, complete .....          | 1 50  |
| Shoes .....                      | 1 25  |
| Wings (each) .....               | 1 00  |
| Handle brackets .....            | 45    |
| Gauge standards .....            | 90    |
| Gauge guides .....               | 30    |
| Gauge .....                      | 1 00  |

#### REPAIR PARTS

##### FOR NOS. 1 AND 2 CAMBRIDGE HORSE HOE

|                                      |         |
|--------------------------------------|---------|
| Pole .....                           | \$ 2 50 |
| Pole braces (each) .....             | 25      |
| Cross piece .....                    | 1 25    |
| Handles, Complete .....              | 1 50    |
| Handles, each .....                  | 65      |
| Handles, round .....                 | 15      |
| Handles, iron .....                  | 25      |
| Handles, brace .....                 | 75      |
| Hammer strap .....                   | 25      |
| Blocks .....                         | 15      |
| Wings .....                          | 2 50    |
| Wing standards .....                 | 2 00    |
| Wing braces .....                    | 25      |
| Disc .....                           | 2 50    |
| Disc bushings .....                  | 50      |
| Disc inside washer .....             | 15      |
| Disc outside washer .....            | 15      |
| Disc standard .....                  | 2 00    |
| Combination bushings or attachments. | 1 00    |
| Wrenches .....                       | 25      |
| Strap irons .....                    | 25      |
| Axle or Bushing Bolt .....           | 25      |

#### CAMBRIDGE IMPLEMENTS.

|                                                          |         |
|----------------------------------------------------------|---------|
| Improved Shovel Plow, adjustable wings and wheel .....   | \$11 50 |
| No. 1 Disc Hoe (without eveners)....                     | 17 20   |
| No. 2 Shovel Hoe (without eveners)...                    | 14 00   |
| No. 3 Shovel Hoe (without eveners)...                    | 14 00   |
| Two-row, one-horse Marker, with Gauge .....              | 14 00   |
| Three-row, two-horse Marker, with Gauge .....            | 18 00   |
| 24" Cambridge Steel Land Roller, 3-section, 8-foot ..... | 57 25   |
| 26" Cambridge Steel Land Roller, 3-section, 8-foot ..... | 63 00   |

Prices on Cambridge Bean Harvester quoted on application.

#### REPAIR PARTS

##### FOR NO. 3 CAMBRIDGE HORSE HOE.

|                           |         |
|---------------------------|---------|
| Pole .....                | \$ 2 50 |
| Cross piece .....         | 1 00    |
| Handles, complete .....   | 1 50    |
| Handles, each .....       | 65      |
| Handles, iron .....       | 25      |
| Handles, rod .....        | 25      |
| Shoe, cast or steel ..... | 50      |
| Upper handle brace .....  | 50      |
| Lower handle brace .....  | 50      |
| Upper pole iron .....     | 65      |
| Lower pole iron .....     | 50      |
| Wing .....                | 2 50    |
| Standard .....            | 2 00    |
| Standard brace .....      | 25      |

#### REPAIR PARTS

##### FOR THE IMPROVED SHOVEL PLOW.

|                                      |         |
|--------------------------------------|---------|
| Beam .....                           | \$ 2 00 |
| Standard .....                       | 2 00    |
| Handles, complete .....              | 1 30    |
| Handles, each .....                  | 65      |
| Handle brace .....                   | 85      |
| Wheel, complete with R. and L. Shank | 2 00    |
| Wheel only .....                     | 70      |
| Wheel Shanks R. H. ....              | 75      |
| Wheel Shanks L. H. ....              | 75      |
| Hook .....                           | 30      |
| Face .....                           | 1 25    |
| Point .....                          | 75      |
| Wings, each .....                    | 1 00    |
| Wing braces .....                    | 30      |
| Center brace .....                   | 40      |

#### REPAIR PARTS FOR THE

##### IRON BEAM CAMBRIDGE SHOVEL PLOW.

|                         |         |
|-------------------------|---------|
| Beam .....              | \$ 3 00 |
| Shoe .....              | 1 00    |
| Point .....             | 1 00    |
| Face .....              | 75      |
| Wings, each .....       | 75      |
| Handles, complete ..... | 1 50    |
| Handles, each .....     | 65      |
| Handles round .....     | 15      |
| Hook .....              | 30      |

For Prices on Other Repairs, see Index on Page 16

## CAMBRIDGE PLOW EXTRAS.

| Number |         | SHARES          |        |       |         |          | MOLDBOARD |       |            |             |      | Frogs and Saddles | Beams | Jointer Moldboards |
|--------|---------|-----------------|--------|-------|---------|----------|-----------|-------|------------|-------------|------|-------------------|-------|--------------------|
|        |         | Plain and Stony | Colter | Steel | Jointer | Landside | Shoe      | Chill | Sol. Steel | S. C. Steel | Shin | Standard          |       |                    |
| 1      | 1-horse | .65             | .80    |       | .25     | 1.00     |           | 3.30  |            |             |      |                   | 4.00  |                    |
| 1      |         | .80             | .95    |       | .25     | 2.25     | .75       |       |            | 7.75        |      | 3.50              | 5.00  | .50                |
| 2      |         | .80             | .95    |       | .25     | 2.25     | .75       |       |            | 7.75        |      | 3.50              | 5.00  | .50                |
| 2      | Rich.   | 1.10            | 1.25   |       |         |          |           | 3.50  |            |             |      | 4.00              |       |                    |
| 5      | S       | 1.10            | 1.25   |       |         |          |           |       |            |             |      |                   |       |                    |
| 7      |         | .80             | .95    |       |         | 1.00     |           | 4.00  |            |             |      | 3.00              | 3.50  |                    |
| 10     |         | 1.10            | 1.25   |       |         |          |           |       |            |             |      | 4.00              |       |                    |
| 11     |         | .90             | 1.05   |       | .25     | 1.25     |           | 5.50  | 7.75       |             |      | 4.00              | 1.50  | 6.50               |
| 12     |         | .90             | 1.05   |       | .25     | 1.25     |           | 5.50  | 8.25       |             |      | 4.00              |       | 6.50               |
| 16A    |         | 1.10            |        |       |         |          | 1.00      | 5.00  | 7.75       |             |      | 4.00              | 1.50  | 3.50               |
| 16B    |         | 1.10            |        |       |         |          | 1.00      | 5.00  | 7.75       |             |      | 4.00              | 1.50  | 3.50               |
| 16C    |         | 1.00            |        |       |         |          | .75       | 5.00  |            |             |      | 3.00              |       | 2.50               |
| 19     |         | .65             | .80    |       | .25     | .90      |           | 3.50  |            |             |      |                   | 4.00  |                    |
| 26     |         | .85             | 1.00   |       | .25     | 2.25     | .75       |       | 7.75       |             | .75  | 4.00              | 6.50  | .50                |
| 27     |         | .85             | 1.00   |       | .25     | 2.25     | .75       |       | 8.25       |             | .75  | 4.00              | 6.50  | .50                |
| 29     |         | 1.10            |        |       | .35     |          | 1.35      |       | 7.75       |             |      | 4.50              | 1.50  | 5.00               |
| 29X    |         | 1.20            |        |       | .35     |          | 1.35      |       | 7.75       |             |      | 4.50              | 1.50  | 5.00               |
| 38     |         | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 8.75       |             | 1.00 | 4.00              | 6.50  | .50                |
| 39     |         | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 8.25       |             | 1.00 | 4.00              | 6.50  | .50                |
| 38     | Sulky   | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 7.75       |             | 1.00 | 4.00              | 8.00  | .50                |
| 39     | Sulky   | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 8.25       |             | 1.00 | 4.00              | 8.00  | .50                |
| 40     |         | .80             | .95    |       | .25     | 2.25     | .75       |       | 7.75       |             | 1.00 | 3.75              | 6.50  | .50                |
| 52     |         | .85             | 1.00   | 4.50  | .25     | 1.50     |           |       | 7.75       |             | .75  | 4.00              | 6.50  | .50                |
| 60     |         | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 7.75       |             | 1.00 | 4.00              | 6.50  | .50                |
| 61     |         | .85             | 1.00   | 4.50  | .25     | 2.25     | .75       |       | 8.25       |             | 1.00 | 4.00              | 6.50  | .50                |

## REPAIR PARTS FOR THE LOVEJOY REVERSIBLE SULKY PLOW.

| Illustrations of Parts on Plate 1. |           |                                |           |
|------------------------------------|-----------|--------------------------------|-----------|
| Beam                               | \$ 8 00   | Stub pole                      | 1 25      |
| Board No. 38                       | 7 75      | Singletree hook or ferrule     | .80R 30   |
| Board No. 39                       | 3 25      | Singletree hook or ferrule     | .80L 30   |
| Landside                           | 2 25      | Wheel cap with set screw       | N62 60    |
| Shin                               | 1 00      | L. H. Lever plunger            | L10 1 00  |
| Standard R. H.                     | AX1 4 00  | R. H. Lever plunger            | L12 1 00  |
| Standard L. H.                     | 61A 4 00  | Foot trip rod                  | STR 50    |
| Shoe                               | 75        | Foot trip Pitman               | SP 30     |
| Point clip                         | 10        | Pole shift lever               | LA1 1 25  |
| Brace                              | 75        | Pole shift lever handle        |           |
| Washer                             | 15        | Pole shift lever dog           | LA5 25    |
| Wheels, plain                      | 6 00      | Pole shift lever Spring        |           |
| Wheel with ratchet N. S.           | 7 50      | Pole shift ratchet             | LA2 75    |
| Ratchet                            | L29 75    | Pole shift bell crank          | LA14 30   |
| Ratchet                            | L30 75    | Pole shift bell crank fastener | LA9 25    |
| Wheel box (O. S.) R. H.            | SB508 75  | Pole shift pitman              | SPS 30    |
| Wheel box (O. S.) L. H.            | SB508 75  | Pole shift 2-horse connection  | 2HS 25    |
| Wheel box (N. S.) R. H.            | L122 1 50 | Pole shift 3-horse connection  | 3HS 25    |
| Wheel box (N. S.) L. H.            | L123 1 50 | Rear pole iron                 | LA3 40    |
| Wheel Box and Ratchet 1917 R. H.   | L124 1 50 | Frame connection               | LA6 50    |
| Wheel Box and Ratchet 1917 L. H.   | L125 1 50 | Middle pole iron               | LA7 50    |
| Wheel retainer                     | LA27 30   | Middle pole iron               | LA8 50    |
| Arch                               | 100 6 00  | Front pole iron                | L8 25     |
| Frame                              | SF 3 00   | Beam Clevis                    | L30 75    |
| Frame extension                    | LA10 4 00 | Small beam clevis (382)        | LA4 40    |
| R. H. axle                         | SRA 3 00  | Hitch rod                      |           |
| L. H. axle                         | SRL 3 00  | Hitch rod stop                 | LA15 15   |
| Short Stud                         | SSA 30    | Hitch rod roller               | HR 15     |
| Long Stud                          | LSA 30    | Hitch rod swivel, complete     |           |
| Lower Beam Coupling                | LA31 1 00 | Seat                           | 1 00      |
| Lower Beam Clip                    | LA19 40   | Seat spring                    | 1 50      |
| Upper Beam Coupling                | SBC 1 00  | Seat spring ratchet            | LA45 75   |
| Bail Hanger Arm                    | L16 90    | Seat spring stop               | LA44 35   |
| Bail Hanger Arm                    | L15 90    | Pole                           | 2 50      |
| Bail Hanger Cap                    | LX 40     | Neck yoke                      | 1 25      |
| Foot rest                          | LA12 2 50 | 3-horse hitch, complete        | 5 50      |
| R. H. Lever                        | L13 3 50  | 2-horse hitch, complete        | 4 50      |
| L. H. Lever                        | L11 3 50  | Singletrees, each              | 75        |
| Lever, complete                    | 5 00      | 3-horse evener                 | 1 50      |
| R. H. Lever Plunger                | L12 1 00  | 2-horse evener                 | 1 00      |
| L. H. Lever Plunger                | L10 1 00  | Straps (each)                  | 30        |
| R. H. Lever hdl. Upper             | L6 35     | Hitch rod complete             | 2 50      |
| R. H. Lever hdl. Lower             | L4 35     | Wheel cap                      | N70 50    |
| L. H. Lever hdl. Upper             | L7 35     | Seat adjusting irons, per set  | 75        |
| L. H. Lever hdl. Lower             | L5 35     | Hub extensions, each           | 1 50      |
| Lever spring                       | 25        | Beam support                   | LA55 1 00 |
| Lever washer                       | L28 10    | Beam support                   | LA58 1 00 |
| R. H. lever ratchet slide          | L2 20     |                                | L65 30    |
| L. H. lever ratchet slide          | L3 20     |                                | L17 75    |
| Foot trip lever                    | LA16 75   | Hanger arm complete            | L15 1 50  |
| Foot trip crank                    | LA17 50   | Hanger arm complete            | L16 1 50  |
| Foot trip stop                     | LA18 20   | Rear beam coupling             | L38 30    |
| Foot trip bell crank               | LA11 30   | Front beam coupling            | L42 30    |
| Foot trip bell crank               | LA13 30   | Axle clip                      | L56 30    |
| R. H. lever ratchet                | L17 1 25  | Axle clip                      | L76 30    |
| L. H. lever ratchet                | L18 1 25  | Foot lever ratchet             | L60 75    |
| Wrench                             | 25        | Foot lever ratchet             | L91 75    |
| Arch marked "Cambridge"            | 6 00      | Foot lever spring              | L91 25    |
| Bushings                           | 20        | Foot lever dog                 | L92 25    |
| Axles complete with hangers (each) | 5 00      |                                | L18 75    |
| Axle washer and pin                | 15        |                                | L39 1 00  |
|                                    |           |                                | L41 75    |
|                                    |           | Sulky Wheel Cap R              | 50        |
|                                    |           | Sulky Wheel Cap L              | 50        |

COLTERS AND PARTS  
FOR CAMBRIDGE PLOWS.

|                                                                                              |         |
|----------------------------------------------------------------------------------------------|---------|
| Colters complete, 29, 29X Plows.....                                                         | \$ 4 00 |
| Colters complete for all one-horse plows .....                                               | 2 50    |
| Colters complete for all 2 and 3-horse plows and sulkies (except No. 29 and 29X plows) ..... | 3 50    |
| Colters less attachments for 2 and 3-horse plows .....                                       | 2 50    |
| Colters less attachments for 1-horse plows .....                                             | 1 75    |
| 29 R. C. Colter block, 29, 29X Plows...                                                      | 75      |
| 29 L. C. Colter block, 29, 29X Plows...                                                      | 75      |
| 29 C. S. Colter Slide, 29, 29X Plows...                                                      | 25      |
| R. & L. Colter block for 16A, 16B Plows                                                      | 75      |
| 16L Colter Slide for 16A, 16B Plows..                                                        | 25      |
| AX16½ Colter Block, 38, 39, 40, 1, 2, 26, 27 Plows .....                                     | 50      |
| AX6 Colter Block 60, 61 Plows.....                                                           | 50      |
| Colter Clip 38, 39, 40, 1, 2, 60, 61, 26, 27, 11, 12 .....                                   | 25      |
| Colter Clip Bar 38, 40, 1, 2, 60, 61, 26, 27, 11, 12 .....                                   | 25      |
| LXX Colter Clipwedge 38, 39, 40, 1, 2, 60, 61 Plows .....                                    | 25      |
| Colter Clipwedge 26, 27 Plows.....                                                           | 25      |
| 12" Rolling Colters complete 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows.....                     | 5 00    |
| 13" Rolling Colters complete 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows.....                     | 5 25    |
| 14" Rolling Colters complete 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows .....                    | 5 50    |

JOINTERS AND PARTS  
FOR CAMBRIDGE PLOWS.

|                                                                            |         |
|----------------------------------------------------------------------------|---------|
| Jointers complete for 29 and 29X Plows .....                               | \$ 4 00 |
| Jointers complete for all 2 and 3-horse plows .....                        | 3 50    |
| Jointers complete for 1-horse Plows...                                     | 2 75    |
| 29RL Jointer Block for 29, 29X Plows                                       | 75      |
| 29LJ Jointer Block for 29, 29X Plows                                       | 75      |
| AX16½ Jointer Block for 38, 39, 40, 1, 2, 26, 27 Plows .....               | 50      |
| AX6 Jointer Block for 60, 61 Plows....                                     | 50      |
| 29JS Jointer Shank for 29, 29X Plows..                                     | 1 25    |
| Jointer Shank for 38, 39, 40, 1, 2, 60, 61, 26, 27, 11, 12 Plows.....      | 1 50    |
| 29JC Jointer Collar 29, 29X Plows.....                                     | 40      |
| 29JS Jointer Slide 29, 29X Plows.....                                      | 25      |
| 29 J. B. Jointer Board 29, 29X Plows....                                   | 75      |
| 29JP Jointer Point 29, 29X Plows.....                                      | 35      |
| Jointer Clip 38, 39, 40, 1, 2, 60, 61, 26, 27, 11, 12 Plows .....          | 25      |
| Jointer Clip Bar 38, 39, 40, 1, 2, 60, 61, 26, 27, 11, 12 Plows .....      | 25      |
| LXX Jointer Clip Wedge 38, 39, 40, 1, 2, 60, 61, 26, 27, 11, 12 Plows..... | 25      |
| Jointer Clip Wedge 26, 27 Plows .....                                      | 25      |
| AX16 Jointer Foot 38, 39, 40, 1, 2, 26, 27 Plows .....                     | 75      |
| Jointer Foot 11, 12 Plows .....                                            | 75      |
| 61D Jointer Foot, 60, 61 Plows .....                                       | 75      |

WHEEL AND PARTS  
FOR CAMBRIDGE PLOWS.

|                                                               |         |
|---------------------------------------------------------------|---------|
| Wheel and Standard comp. with attach 1-horse Plow .....       | \$ 1 50 |
| Wheel and Standard comp. with attach 2 and 3-horse Plow ..... | 1 75    |
| Wheel and axle complete for all Plows                         | 1 10    |
| Wheel only for all Plows .....                                | 60      |
| 29 W. S. Wheel Standard for 29, 29X Plows .....               | 50      |
| W. S. Wheel Standard for 38, 39, 40, 1, 2, 26, 27 Plows ..... | 50      |
| Wheel Standard for 60, 61, 16A, B. & C. Plows .....           | 50      |
| Wheel Standard for 11, 12 Plows.....                          | 35      |
| 10 D. R. Wheel Block 29, 29X Plows..                          | 30      |
| 10 D. L. Wheel Block 29, 29X Plows..                          | 30      |
| R. & L. Wheel Block 16A, 16B, 16C Plows .....                 | 25      |
| AX14 Wheel Block 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows.....  | 30      |
| AX15 Wheel Block 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows.....  | 30      |
| Wheel Block 11, 12 Plows .....                                | 30      |
| 29WF Wheel Ferrule 29, 29X Plows....                          | 15      |
| Wheel Ferrule for all other Plows....                         | 15      |

HANDLES AND PARTS  
FOR CAMBRIDGE PLOWS.

|                                                                  |         |
|------------------------------------------------------------------|---------|
| Handles complete for all Plows except No. 1 one-horse Plow ..... | \$ 1 75 |
| Handles complete, No. 1 one-horse Plow .....                     | 1 50    |
| Handles single for all Plows except No. 1 one-horse Plows .....  | 75      |
| Handles single for No. 1 one-horse Plow .....                    | 65      |
| Handle Rounds .....                                              | 15      |
| 16A Handle Braces 29, 29X Plows (per pair) .....                 | 75      |
| Handle Braces, Upper, 16A, 16B, 16C Plows .....                  | 60      |
| Handle Braces, Lower, R. or L., 16A, 16B, 16C Plows .....        | 50      |
| AX10 Handle Braces, Upper, 38, 39, 40, 1, 2 Plows .....          | 75      |
| Handle Braces, Upper, 60, 61 Plows...                            | 75      |
| Handle Braces, Lower 60, 61 Plows....                            | 50      |
| Handle Braces, R. or L., 60, 61 Plows.                           | 25      |
| LHB Handle Braces, L. H., 26, 27 Plows .....                     | 40      |
| RHB Handle Braces, R. H., 26, 27 Plows .....                     | 40      |
| Handle Braces, 11, 12 Plows .....                                | 25      |
| U. H. R. Upper Handle Rod, 38, 39, 40, 1, 2, 26, 27 Plows .....  | 25      |
| Upper Handle Rod, 60, 61 Plows.....                              | 25      |
| AX10½ Upper Handle Brace Attachment, 38, 39, 40, 1, 2 Plows..... | 40      |
| AX11 Lower Handle Brace Attachment, 38, 39, 40, 1, 2 Plows.....  | 50      |
| Upper Handle Brace, 60, 61 Plows.....                            | 40      |
| LHR Lower Handle Rod, 26, 27 Plows                               | 40      |
| AHB Lower Handle Brace L. H. 38, 39, 40, 1, 2 Plows .....        | 40      |
| LHB Lower Handle Brace R. H. 38, 39, 40, 1, 2 Plows .....        | 40      |
| RHI Handle Iron R. H. 26, 27 Plows..                             | 40      |
| LHI Handle Iron L. H. 26, 27 Plows...                            | 40      |
| Handle Iron, 11, 12 Plows .....                                  | 50      |
| L. H. 27 O. S. Adj. Hdl. 26, 27 Plows..                          | 50      |
| R. H. 27 O. S. Adj. Hdl. 26, 27 Plows..                          | 50      |
| L. H. Adj. Hdl. 11, 12, 7 Plows.....                             | 50      |
| R. H. Adj. Hdl. 11, 12, 7 Plows.....                             | 50      |
| Handle Iron, No. 1, one-horse Plow....                           | 25      |
| H. W. Handle Washer 26, 27 Plows....                             | 10      |

CLEVISES AND PARTS  
FOR CAMBRIDGE PLOWS.

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| 2-horse Clevis complete with ring, 26, 27 Plows .....               | \$ 1 00 |
| 3-horse Clevis complete with ring, 26, 27 Plows .....               | 1 25    |
| 61E 3-horse Clevis 60, 61 Plows.....                                | 85      |
| AX13 3-horse Clevis 38, 39, 40, 1, 2, 26, 27 Plows .....            | 85      |
| 10A Clevis 29, 29X Plows .....                                      | 85      |
| Clevis 16A, 16B Plows .....                                         | 2 00    |
| Clevis 16C Plow .....                                               | 1 00    |
| AX23 Clevis 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows .....            | 60      |
| Clevis 11, 12 Plows .....                                           | 75      |
| Clevis 1 one-horse Plow .....                                       | 60      |
| Clevis No. 7 two-horse Plow .....                                   | 60      |
| Small or End Clevis 16C Plow.....                                   | 25      |
| D. C. Small Clevis 38, 39, 40, 1, 2, 60, 71, 26, 27 Plows .....     | 20      |
| Small Clevis 11, 12, 7, and No. 1 one-horse Plow .....              | 20      |
| Shifting Clevis complete for 29, 29X Plows .....                    | 2 00    |
| D. P. Small Clevis Pin 38, 39, 40, 1, 2, 60, 61, 26, 27 Plows ..... | 10      |
| Small Clevis Pin 11, 12, 7, No. 1 one-horse Plow .....              | 10      |
| 10C Draw Hook 29, 29X Plows .....                                   | 50      |
| 10CL Draw Hook Link 29X Plows .....                                 | 10      |
| Shift Rod 16A, 16B, 16C Plows.....                                  | 1 00    |
| Hook 16A, 16B, 16C Plows .....                                      | 50      |

For Prices on Other Repairs see Index on Page 16.

**MISCELLANEOUS PARTS.**

|                                       |       |                                          |      |
|---------------------------------------|-------|------------------------------------------|------|
| 29 I Crotch 29, 29X Plows .....       | \$ 85 | 29R O. S. Latch Dog 29, 29X Plows....    | 25   |
| 29CB Crotch Bolt 29, 29X Plows.....   | 30    | Latch 16A, 16B, 16C Plows.....           | 75   |
| A Crotch 16A Plow .....               | 1 00  | Latch Dog 16A, 16B, 16C Plows .....      | 15   |
| B Crotch 16R Plow .....               | 1 00  | Spring 16A, 16B, 16C Plows .....         | 30   |
| C Crotch 16C Plow .....               | 75    | Spring Washer 16A, 16B, 16C Plows..      | 10   |
| 29K Standard Brace 29, 29X Plows....  | 75    | Long Pitman 16A, 16B Plows .....         | 75   |
| 29J Latch 29, 29X Plows .....         | 75    | Short Pitman 16A, 16B Plows .....        | 30   |
| 29LX Latch Arm L. H. 29, 29X Plows... | 30    | Foot Latch complete 16A, 16B Plows..     | 2 25 |
| 29RX Latch Arm R. H. 29, 29X Plows    | 30    | Point Clip 38, 39, 40, 1, 2, 60, 61, 26, |      |
| 29L-W. Lever Washer 29, 29X Plows.    | 10    | 27 Plows .....                           | 10   |
| 29S Spring, 29, 29X Plows .....       | 30    | AX12 Beam Head 38, 39, 40, 1, 2, 60, 61, |      |
| 29SW Spring Washer 29, 29X Plows ..   | 10    | 26, 27 Plows .....                       | 50   |
| 29SL Shifting Lever 29, 29X Plows.... | 1 00  | Rub Iron 38, 39, 40, 1, 2, 60, 61, 26,   |      |
| 29 H. B. Beam End 29, 29X Plows ....  | 50    | 27 Plows .....                           | 25   |
| 29LP Long Pitman 29, 29X Plows.....   | 75    | B. W. Beam Washer 38, 39, 40, 1, 2       |      |
| P2 Short Pitman 29, 29X Plows .....   | 30    | Plows .....                              | 10   |
| Pitman complete 29, 29X Plows .....   | 1 25  | Beam Washer 60, 61 Plows .....           | 10   |
| M Foot Latch complete 29, 29X Plows   | 2 50  | 10-B Guide Base End on Beam 29 Plow      | 40   |
| 29-G Inner Shoe and Rivets .....      | 1 50  |                                          |      |

**BOLTS.**

|                                                            |       |                                                          |    |
|------------------------------------------------------------|-------|----------------------------------------------------------|----|
| Machine and Carriage, under 5" (ex-<br>cept special) ..... | \$ 05 | Machine and Carriage over 5" (ex-<br>cept special) ..... | 06 |
| Set Screws, all sizes for plows.....                       | 08    | All Plow Bolts .....                                     | 06 |
| Cap Screws, all sizes for plows.....                       | 08    | Screw Head Bolts for O.S. Shin.....                      | 10 |

**INDEX FOR LE ROY PLOWS, IMPLEMENTS AND REPAIRS.**

|                                  |     |
|----------------------------------|-----|
| Bolts .....                      | 7   |
| Beams .....                      | 3   |
| Colters and Parts.....           | 5   |
| Clevises .....                   | 5   |
| Cultivator Parts .....           | 7   |
| Hillers .....                    | 2   |
| Hiller Extras .....              | 6   |
| Handles and Parts.....           | 4   |
| Jointers and Parts.....          | 3   |
| Lardsides, Shoes and Shins.....  | 3   |
| Marker Parts .....               | 6   |
| Moldboards .....                 | 3   |
| Miscellaneous .....              | 4   |
| Plows, Walking and Sulky.....    | 2   |
| Roller Parts .....               | 6   |
| Sulky Plow Parts.....            | 5-6 |
| Shares and Jointer Points.....   | 3   |
| Standard, Frogs and Saddles..... | 3   |
| Wheels and Parts.....            | 4   |
| All Implements .....             | 2   |
| Shovel Plow Parts.....           | 6   |
| Beam Harvester Parts.....        | 7   |

**INDEX FOR CAMBRIDGE PLOWS, IMPLEMENTS AND REPAIRS**

|                                                                                           |    |
|-------------------------------------------------------------------------------------------|----|
| Bolts .....                                                                               | 16 |
| Beams, Shares, Landsides, Shoes, Moldboards, Shins, Standards, Frogs and<br>Saddles ..... | 14 |
| Clevises, Colters, Jointers, Wheels and Handles.....                                      | 15 |
| Cambridge Horse Hoes .....                                                                | 13 |
| Marker and Parts.....                                                                     | 13 |
| Miscellaneous .....                                                                       | 16 |
| Shovel Plows and Parts.....                                                               | 13 |
| Plows, Walking and Sulky.....                                                             | 13 |
| All Other Implements.....                                                                 | 13 |
| Sulky Plow Parts.....                                                                     | 14 |