

1882.

PRICE LIST
OF
THE CASADAY
Sulky and Gang Plows

MANUFACTURED BY THE
OLIVER
Chilled Plow Works.
SOUTH BEND,
Indiana.



Price List

Casaday Sulky Plow.

Letters O. H. P. &c., designate manner in which plows are fitted. In ordering, all that is necessary, is to say if Right or Left Hand is wanted, give number and kind of bottom and initial letter, designating how plows should be rigged.

- H**—Sulky Plow. Steel or Chilled Mould, Steel }
Share, Rolling Coulter, Weed Hook and } **\$60 00**
Three-horse eveners, Iron Wheels.
- O**—Sulky Plow. Steel or Chilled Mould, Cast }
Shares, Rolling Coulter, Weed Hook and } **56 50**
Three-horse eveners, Iron Wheels.
- P**—Sulky Plow. Steel or Chilled Mould, Cast }
Shares, Chilled Jointer, Weed Hook and } **55 00**
Three-horse eveners, Iron Wheels.
- B**—Sulky Plow. Steel or Chilled Mould, Cast }
Shares, Chilled Jointer, Weed Hook and } **50 00**
Iron Wheels.
- Steel Jointer, extra, 50 cents.

PLOW BOTTOMS.

The following are the leading patterns used :

- No. 16. { Steel or Chilled Moulds, steel or cast } Cuts
 { Shares. General purposes, } 16 inches
- " 17. { Steel Moulds, steel or cast Shares. } Cuts
 { For stubble, Right hand only. } 16 inches.
- " 76. { Steel or Chilled Moulds, steel or cast } Cuts
 { Shares. General purposes, } 14 inches.
- " J 1. Prairie Breaker, all steel—cuts 14 to 16 inches.
 Right hand only.

EXTRAS.

Plow Bottoms—14 or 16 inch, with Steel or Chilled } Mould and Steel Share.	16 00
Plow Bottoms—14 or 16 inch, with Steel or Chilled } Mould and Cast Share.	12 50
Prairie Breaker Bottoms—14 or 16 inch, Steel, } with extra Share.	16 00
The following parts fit either Right or Left Hand Plows :	
Wood Beams. Finished-----	2 00
Tongues "-----	2 00
Tongue Straps,-----	50
Neck-yokes. Finished and ironed-----	1 25
Neck-yoke Bolts, per set-----	20
" " Plates, "-----	10
" " Ferule and Rings, per set-----	30
Rolling Coulters, complete, with beam plate-----	5 00
" " Blades only-----	2 50
" " Cranks (wrought)-----	50
" " Centres. per set, complete-----	50
" " Cone bearings, per set-----	25
" " Centre pins, each-----	10
" " Eye Bolts-----	30
" " Yokes, No. 78 (malleable)-----	1 00
" " Beam Plates, N & 93-----	45
" " Clamp Cone,-----	15
" " Collar, with set screw-----	25
Three-Horse Eveners, complete-----	5 00
Two-Horse double-trees, complete-----	2 50
Single-trees, finished and ironed-----	75
Clips and Hooks for singletree, per set,-----	30
Double-tree bars, finished-----	75
Long bars for 3 horse eveners, finished-----	1 00
Top bars for " "-----	50
Large Hooks for 3-horse eveners-----	40
No. 209 3-Horse Equalizer Bar-----	1 00
" 210 3-Horse Equalizer Clevis, each-----	50
" 212 3-Horse Equalizer Clevis-----	50
Three-Horse Evener Clamp,-----	20
" " " Straps, per set,-----	25
Double-tree clevises-----	40
Seats-----	1 25
Seat springs-----	1 25
Compression springs (Land wheel)-----	1 00
Spiral lever " (brass)-----	15
Brace Rod (wrought)-----	1 00
Draft " "-----	1 00
Upper Frame Bar (wrought)-----	1 50
Lifting wire "-----	15
" plunger "-----	20
Lever Rollers,-----	20
Wrench, malleable,-----	35
Weed Hooks, complete-----	75
Weed Hook Plates, Nos. 184 and 185, per pair-----	15
Oil Cans-----	15
Oil Can Holders-----	25
Loose Collars-----	10
Linch Pins-----	05
Spindle Washers-----	05
Bevel Head Bolts-----	05
Share "-----	05
Seat Bolts,-----	05
Draft Rod Eye Bolts,-----	20
3/8 in. machine Bolts-----	10
1/2 in. " "-----	15
Over 1/2 in. machine Bolts-----	20

EXTRAS.

No. 33	Lever Clamp, malleable,-----	25
" 120	Furrow wheel spindle.-----	1 25
" 129	Spindle ratchets-----	10
" 133	Seat Clamp-----	15
" 136	Sector-----	75
" 146	Tongue, iron-----	50
" 147	Dial plate-----	20
" 186	Brace Rod Lever-----	1 00
" 187	Plunger-----	15
" 208	Double Spindle Washer-----	15

In ordering any of the following parts, say if right or left hand is wanted :

Steel or Chilled Moulds, 14 to 16 inch-----	6 00
Steel Shares, 14 to 16 inch-----	4 75
Cast " " " plain-----	60
" " " " cutter-----	70

 In ordering Standards, say whether for steel or chilled moulds.

Standards, all Nos., each-----	5 00
--------------------------------	------

Parts of Right Hand Plows.		Parts of Left Hand Plows.		
Nos. 37	36	Latches, malleable, each	15	
" 88	89	Spring cases "	75	
" 116	131	Double Latches "	20	
" 122	121	Side uprights "	3 50	
" 124	123	Sectors "	75	
" 128	137	Foot rests "	1 00	
" 132	141	Land Wheel Spindles-----	2 50	
" 140	151	Beam plates-----	3 50	
" 148	149	Tongue irons, each-----	50	
" 166	166	Land Levers-----	1 50	
" 170	171	Landside Frame Parts,-----	2 00	
" 180	180	Lifting Levers, each-----	1 25	
" 182	181	Lifting Lever, foot, each,	1 00	
" 188	189	Brace Rod Sector "	75	
Brace Rod Lever, and connections-----			2 25	
Lower Frame Bar-----			1 50	
Stony Land Plate-----			30	

 Say whether for Right or Left Hand Plow, or for land or furrow wheels.

Iron wheels, complete, each-----	5 00
Skein boxes, complete with screw cap-----	60
Skein Boxes only-----	35
Screw Caps "-----	25
Jointer, complete (chilled)-----	2 50
" " steel-----	3 00
Jointer, Mould-board (chilled)-----	50
" " and Shares, steel (in one } piece)	1 00
" Holders (malleable)-----	1 50
" Standards (malleable)-----	75
Jointer Points, chilled-----	20


PRICE LIST

Casaday Gang Plow.


Twelve-inch, Chilled or Steel Mould }
Boards, Steel Points Complete, } **\$85 00**
Right Hand Only, }

EXTRAS.

No. 152	Lifting Lever-----	2 00
" 190	Brace Rod Sector-----	75
" 192	Beam Plate-----	3 50
" 193	Tongue Iron and Chains-----	2 00
" 194	" "-----	50
" 195	Rolling C Bracket-----	1 50
" 196	Tongue, Iron-----	50
" 197	Foot Lever-----	1 25
" 198	" " Support-----	1 00
" 199	Dial Plate "-----	1 25
" 201	R. C. Block-----	50
" 202	Furrow Spindle-----	1 50
" 203	Side Upright-----	3 50
" 216	Washer Spindle-----	25
" 217	Land Lever Stop-----	25
" 218	Tooth Sector Plate-----	25
" 219	Sector-----	75
" 220	Standard (Chilled)-----	3 00
" 221	Foot Brace-----	35
" 224	Land Spindle-----	2 50
" 215	Landside Sector-----	75
" 222	Land Lever-----	1 50
" 223	Landside Frame part-----	2 00
" 225	Draft Rod Shackle-----	25
	Long Beam, Wrought Iron-----	5 50
	Short " "-----	5 50
	Rolling Coulter, Malleable Yoke, No. 78-----	1 00
	Compression Spring-----	1 25
	Spiral Lever Spring, (Brass)-----	25
	Brace Rod, Wrought-----	1 00
	Draft " Complete-----	1 25
	Seat Spring-----	1 50
	Brace Rod Lever, Complete-----	2 25
	Top or Bottom Bar, each-----	1 25



Casaday Sulky Plow.



Casaday Gang Plow.

M 95A
DM

Special Notice.

Our plows are well made, of the best material, and will scour in any soil where others of their class will.

Breakages are made good only when manifest defect in the material is shown.

No goods to be returned to us without our permission, in which case they may be replaced or credited in account, at our option.

Hardened Steel Shares are not warranted against breakage, except when defective material or workmanship is the cause. These shares should be ground when they need sharpening and not put into a blacksmith's fire where they are liable to be spoiled.

All claims for shortage must be made within five days from receipt of goods, to insure attention.

Our responsibility ceases when we have delivered goods to the transportation companies and received a receipt in good order. The fault after that is with the transportation companies, and claims for loss or damage should be made to them.

When sending us plows or parts of plows for repairs, always put your address, as well as ours on shipping tag, and advise us by mail, giving full instructions, and be sure to send shipping bill on which is stated, "For Repairs."

We will not undertake to pay for repairing plows away from the shop.

In ordering plows or parts, state whether right or left hand. In the absence of instructions, right hand will be sent.