

1897

RETAIL PRICE LIST
of

PLOWS
& EXTRAS

GALE
MFG CO.

ALBION, MICH., U.S.A.

BRANCH HOUSES

ALL OVER THE COUNTRY.



ALBION, MICH., MARCH, 1889.

The Within Prices are Absolutely Net.

Dealers will Adhere Strictly
to them.

DESTROY ALL PREVIOUS LISTS.



PRICE LIST.



GALE MFG. CO.

ALBION, MICHIGAN,

U. S. A.



BRANCH HOUSES.

Rochester, N. Y.

Harrisburgh, Pa.

Columbus, Ohio.

Kansas City, Mo.

Cedar Rapids, Iowa.

San Francisco, Cal.

Portland, Oregon.

Lexington, Ky.

St. Louis, Mo.

Bloomington, Ill.

Indianapolis, Ind.

Milwaukee, Wis.

Salt Lake City, Utah.

Sacramento, Cal.

Los Angeles, Cal.

Lincoln, Neb.

STEEL "BIG INJUN" SULKY PLOW.

STYLES RIGHT OR LEFT HAND.

B 1-14 in G. P., Turf and Stubble	\$54.00
B 1-15 in G. P., Turf and Stubble	54.00
B 7-16 in G. P., Turf and Stubble	54.00
B 8-16 in Stubble	54.00
B 5-14 in Stubble	54.00
B 6-16 in Stubble	54.00
B 2, General Purpose	54.00
B 4, General Purpose	54.00

Above prices include Pole, Tripletrees, Neck Yoke, Rolling Coulters, and Weed Hook.

WALKING PLOWS.**STUBBLE PLOW.**

STYLES RIGHT OR LEFT HAND.

STEEL BEAM. DOUBLE SHIN.

H 12 in. Cut	\$16.25
H 13 in. Cut	17.50
H 14 in. Cut	19.00
H 16 in. Cut	21.50

WOOD BEAM. DOUBLE SHIN.

H 12 in. Cut	\$14.75
H 13 in. Cut	16.00
H 14 in. Cut	17.25
H 16 in. Cut	19.50

GENERAL PURPOSE PLOWS.

STEEL BEAM. DOUBLE SHIN.

H 3-14 in. Cut	\$19.00
H 3-15 in. Cut	19.75
H 7-16 in. Cut	21.50

WOOD BEAM. DOUBLE SHIN.

H 3-14 in. Cut	\$17.25
H 3-15 in. Cut	18.00
H 7-16 in. Cut	19.50

TIMBER LAND PLOWS.

STEEL BEAM.

H 2, General Purpose	\$17.00
H 4, General Purpose	16.50

T. L. PLOW.

WOOD BEAM.

H 2, General Purpose	\$16.00
H 4, General Purpose	15.50

All Steel Plows are made of Hardened Soft Centre Steel.

"BIG INJUN" SULKY, CHILLED.

15 A, Chilled, Right	\$47.00
27 A, Chilled, Right	47.00
26, Chilled, Right	47.00
31, Chilled, Right	47.00
29, Chilled, Left	47.00
30, Chilled, Left	47.00
30 B, Chilled, Left	47.00

Above prices include Pole, Tripletrees, Neck Yoke, Jointer, and one extra Share.

"BIG INJUN" COMBINATION.**STYLES RIGHT OR LEFT HAND.**

B 2, Steel Mbd. and Landside, Cast Share	\$49.50
B 4, Steel Mbd. and Landside, Cast Share	49.50

Above prices include Pole, Tripletrees, Neck Yoke, Jointer, and extra Cast Share.

WALKING PLOWS.

15 A, Wood Beam, Chilled, Right	\$11.50
17 B, Right	8.00
24, Iron Beam, Right	10.50
24, Iron Beam, Steel Moldboard, Right	11.50
24, Steel Beam, Chilled, Right	11.50
26, Wood Beam, Right	11.00
26, Wood Beam, Steel Moldboard, Right	12.00
27 A, Wood Beam, Right	11.00
31, Wood Beam, Right	10.50
32, Wood Beam, Slanting Landside, Right	10.00
34, Wood Beam, Slanting Landside, Right	11.00
29, Wood Beam, Left	10.50
30, Wood Beam, Left	11.00
30 B, Wood Beam, Left	11.00
33, Wood Beam, Left	10.00
35, Wood Beam, Right	5.00
20 A, Wood Beam, Right	10.50

STEEL BEAM COMBINATION.

No. 240, Steel Moldboard, Cast Landside and Share	\$12.50
No. H 2, Steel Moldboard and Landside, Cast Share	15.50
No. H 4, Steel Moldboard and Landside, Cast Share	15.00

WOOD BEAM COMBINATION.

26, Steel Moldboard, Cast Landside and Share	\$12.00
H 2, Steel Moldboard and Landside, Cast Share	14.00
H 4, Steel Moldboard and Landside, Cast Share	13.50

Clevis, extra Point and Wrench included, but Wheel and Jointer are not included in above price.

EXTRAS FOR STEEL PLOWS— MOLDBOARDS.

No. A 4, 24, 26, 39, 42, and 240	\$4.50
All other sizes	5.00

STANDARDS.

Frog for No. 24 and 240 R. H. Steel Beam	\$2.50
Frog for Steel Beam Plows, all sizes	2.50
Frog for Wood Beam Plows, all sizes	2.50
Wrought Standard and Cap for Wood Beam Plow, all sizes	2.50

LANDSIDES.

Steel Landsides, 12, 13, and 14 in. with Bolts	\$2.00
Steel Landsides, 15 and 16 in. with bolts	2.50
Steel Landsides, Big Injun with Bolts, all sizes	2.00

STEEL SHARES.

H 2, H 4, 12 and 13 in.	\$3.50
H 3, 14 and 15 in. H 12, H 13, H 14, B 5, (Hardened)	4.00
B 6, B 7, B 8, H 16, and H 7, (Hardened)	4.50
Steel Fin Cutters, "Hardened"	1.00
Jointer Rigs, "Steel"	2.50
Jointer M Board and Point, "Hardened" Steel	.75
Jointer Arm and Block, see page 19.	

ROLLING COULTER RIGS.

Rolling Coulters, 14 in., complete, for Walking Plows, \$4.00	
Rolling Coulters, 16 in., complete, "Big Injun"	4.00
Rolling Coulters, Shank	.50
Rolling Coulters, Clamp	.50
Rolling Coulters, Yoke	1.00
Rolling Coulters, Cones, per pair	.20
Rolling Coulters, Sides or Axles	.50

STANDARD KNEE COULTERS.

All Numbers	\$1.50
Standard Knee Coulters Block	.20
Standard Knee Coulters Blade, Steel	1.25
Standard Knee Coulters Arm Bolt	.15

BEAM COULTERS.

All Numbers	\$2.00
Beam Coulters Holder, Malleable	.80
Beam Coulters Steel Blade, Hanging	1.00
Beam Coulters, Beam Bolt	.10
Beam Coulters, Blade Bolt	.10

WHEEL RIGS.

All Numbers complete, with Bolts	\$1.00
Wheels only	.40
Wheel Standard or Jacks, Cast or Malleable	.40
Wheel Axles or Arbors	.20
Wheel Axle Sand Caps	.05
Wheel Axle Bolt	.05

CLEVISES FOR STEEL PLOWS.

Clevis for Steel Beam, complete	\$.75
Clevis for Wood Beam, complete	.75
Clevis Jaws for Steel or Wood Beam Plow, pair	.60
Cross Clevis for Steel or Wood Beam, each	.35

HANDLES.

Straight Handles, finished for Steel Beam Plows, each	\$.50
Straight Handles, finished per pair, "loose"	1.00
Straight Handles, finished per pair, complete	1.50
Handle Rounds, finished, each	.10
Handle Bolts, long, each	.10
Handles, Index, each	.50
Braces for Steel Beam Walking Plows, each	.40

BEAMS.

Steel Beams, all sizes, plain, finished	\$4.00
Wood Beams, all sizes, plain, finished	1.25

BOLTS.

See page 21.

**REPAIRS FOR TWO WHEEL "GALE"
SULKY PLOW.**

16 in. Steel bottom and Steel Beam	\$23.00
14 in. Steel Bottom and Steel Beam	22.00
16 in. Steel Bottom and Steel Beam Breaker	23.00
14 in. Steel Bottom and Steel Beam Breaker	22.50
16 in. Chilled Bottom and Steel Beam	16.00
15 in. Chilled Bottom and Steel Beam	15.00
14 in. Chilled Bottom and Steel Beam	15.00
12 in. Chilled Bottom and Steel Beam	14.00
16 in. Steel Bottoms	16.00

14 in. Steel Bottoms	15.50
16 in. Steel Breaker Bottom	16.50
14 in. Steel Breaker Bottom	16.50
16 in. Chilled Bottom, No. 15 S	10.00
15 in. Chilled Bottom, No. 27 S	9.00
14 in. Chilled Bottom, No. 26	9.00
12 in. Chilled Bottom, No. 31	9.00
Steel Beams for either of above sizes	6.00

Parties desiring new bottoms fitted to old beams should forward the beam to factory to insure perfect satisfaction in the adjustment.

Price for fitting new bottom to old beam 1.00

EXTRAS FOR SULKY BOTTOMS.

16 in. Steel Moldboard	\$5.00
14 in. Steel Moldboard	5.00
16 in. Steel Moldboard, for Breaker	5.00
14 in. Steel Moldboard, for Breaker	5.00
16 in. Chilled Moldboard, No. 15 S	3.50
15 in. Chilled Moldboard, No. 27 S	3.50
14 in. Chilled Moldboard, No. 26	3.50
12 in. Chilled Moldboard, No. 31	3.50
16 in. Steel Shares with Bolts	4.50
14 in. Steel Shares with Bolts	4.00
16 in. Steel Shares with Bolts, for Breaker	4.00
14 in. Steel Shares with Bolts, for Breaker	3.50
16 in. Chilled Shares, No. 15 A	.35
15 in. Chilled Shares, No. 27 A	.35
14 in. Chilled Shares, No. 26	.35
12 in. Chilled Shares, No. 31	.35
16 in. Steel Landside	2.50
14 in. Steel Landside	2.00
16 in. Chilled Landside, No. 15 S	1.00
15 in. Chilled Landside, No. 27 S	1.00
14 in. Chilled Landside, No. 26	1.00
12 in. Chilled Landside, No. 31	1.00
16 in. Chilled Base or Standard, No. 15 S	3.00
15 in. Chilled Base or Standard, No. 27 S	2.75
14 in. Chilled Base or Standard, No. 26	2.75
12 in. Chilled Base or Standard, No. 31	2.50

REPAIRS FOR "TWO WHEEL" SULKY, CARRIAGE.

Arch to Frame	\$4.00
Front to Frame	3.00
Bail	2.50
Slide Axle, complete, No. 32, old style	2.50
Slide Axle, complete, No. 55, new style with set screw	2.50
Lifting Lever, complete, Right Hand	2.50
Connecting Rod on Lever, each	.25
Lifting Lever Bar	.75
Lifting Springs, each	.15
Slide Axle Lever	2.00
Saddle, flexible, with Set Collar, old style	2.00
Saddle, flexible, with Set Collar, new style, foot trip	3.00
Wheels, Land, complete, old style, No. 67 with box	4.25
Wheels, Land, complete, new style, No. 68 with box	4.25
Wheels, Furrow, complete, No. 67 or 68 with box	4.75
Seat	1.25
Seat Spring	2.00
Bail Bolt, Left Hand Side	.25
Dog and Lever Bolt	.20
Pole Clamp with Bolt and Seat Clamp, each	.25
Pole Bracket Bolt, lower	.10
Pole Bracket Bolt, upper	.10
Beam Clamp Bolts, each	*10*
Weed Hook and Bolt	1.00

MALLEABLE PARTS.

No. 24	Front Pole Casting	\$.35
No. 29	Left Hand Lever Arch	1.25
No. 30	Right Hand Lever Arch	1.50
No. 31	Lever and Bail Brace	2.00
No. 32	Sliding Axle Slide, old style	.75
No. 55	Sliding Axle Slide, new style with set screw	.75
No. 33	Ferule for Axle, left hand	.10
No. 34	Lever Socket, both sides	.15
No. 35	Arch Dog	.15
No. 36	Latch Handle for Left Hand Lever	.25
No. 37	Beam Clip, old style	.30
No. 64	Beam Clip, new style	.30
No. 38	Set Collar for Bail	.25
No. 39	Lifting Dog	.25

No. 40	Latch Handle or Lift Lever, Right Hand .	.30
No. 41	Foot Rest	.50
No. F. 56	Foot rest extensions, each	.20
No. 62	Lever to new style saddle	.50
No. 61	Front Pole Strap	.25

CAST PARTS.

No. 71	Tool Box	\$.40
No. 44	Lifting Dog Wedge	.15
No. 45	Hub Lever Washer	.10
No. 46	Beam Adjuster, Malleable	.10
No. 47	Box to land wheel, old style	.50
No. 60	Box to land wheel, new style, heavy	.50
No. 48	Box and Ratchet, R. H. Wheel, old style	.75
No. 59	Box and Ratchet, R. H. Wheel, N. S. heavy	.75
No. 49	Saddle, complete rigged	1.50
No. 50	Pole Bracket, old style	.50
No. 56	Pole Bracket, new style	.50
No. 51	Inside Axle Washer, small	.15
No. 72	Inside Axle Washer, new style, large	.15
No. 52	Bail Washer	.10
No. 53	Casting between arch and frame	.10
No. 63	Axle Thimble, each, new style	.10
	Saddle, N. S. flexible, complete with Foot Trip	3.00
No. 57	Upper Plate to Saddle	1.00
No. 58	Lower Plate to Saddle	1.25
No. 65	Washer on under side	.10
	Large Bolt for Saddle	.25
	Spring to trip on Saddle	.05
No. 38	Set Collar for Saddle on bail	.25
	Saddle flexible, N. S. with pin	2.50
No. 73	Upper Saddle Plate	.85
No. 74	Lower Saddle Plate	1.15
No. 65	Saddle Washer	.10
No. 70	Saddle Pin	.10
	Large Bolt for Saddle	.25
No. 38	Set Collar for Saddle on bail	.25
	Weed Hook, complete	1.00

WOODEN PARTS.

	Pole, finished	\$2.50
	Neck Yoke, complete	1.25
	Tripletrees, complete	4.00

Doubletrees, large, each	.75
Doubletrees, small, each	.50
Singletrees	.35
Clevises	.25
Hooks, complete	.15
Wrench (screw)	.60

JOINTERS AND EXTRAS.

Jointer Rigs, complete, Wrought or Cast, Extra Point	\$2.50
Jointer Arms, Wrought	1.00
Jointer Head, Malleable	.40
Jointer Moldboard	.40
Jointer Point	.20
Jointer Blocks, Malleable	.25
Beam Blocks, Malleable, for Steel Beam only	.50
Jointer Arm Bolt	.10
Jointer Arm Cast	1.50

ROLLING COULTERS AND EXTRAS.

Rolling Coulter Rigs, complete	\$4.00
Rolling Coulter Yoke, Malleable	1.00
Rolling Coulter Shank	.60
Rolling Coulter Clamp	.50
Rolling Coulter Guide Screw	.10
Rolling Coulter Hubs	.25
Rolling Coulter Hubs, Cones, per pair	.20
Rolling Coulter Blades with Hubs	2.00
Rolling Coulter Yoke Bolts	.10

CLEVIS PARTS.

Clevis Rigs for Sulky, complete	\$1.50
Clevis Jaws, A and B	.40
Clevis Crosshead, C	.40
Clevis Swivel, D	.40
Clevis Braces, E and F, each	.15
Clevis Pin, long	.10
Clevis Pin, short	.05
Clevis Bolt	.05

REPAIRS FOR "BIG INJUN" SULKY PLOWS.

Always say in ordering if for Right or Left Hand Sulky.

Steel Bottoms, all sizes, Soft Steel Center, Hardened	
Shares	\$15.00
Chilled Bottoms, all sizes	9.00
Combination Bottoms, Steel Moldboards and Land-	
side, Cast Shares, all sizes	12.50
Steel Sulky Beam	4.20
Main Frame Side Beam	2.64
Main Frame Arch	3.00
Middle Frame Piece	1.50
Land Wheel	3.00
Front Furrow Wheel	2.52
Rear Furrow Wheel	2.10
Seat Spring	2.00
Levers, each, Right and Left Hand, complete	1.50
Trip Chains	.60
Axle for Land Wheel	1.50
Axle for Furrow Wheel	.75
Pole Standard	1.50
Seat	1.25
Tool Box	.60
Cast Spool or Axle for Rear Wheel	.30
Wheel Boxes for Land and Large Furrow Wheel	.30
Clevis G	.60
Swivel Clevis, complete	.60
Front End Steel Draw Bolt and Nuts	.75
Bolts and Set Screws, each	.12
B 1 Malleable	1.05
B 2 Malleable	.75
B 3 Side Clevis on Beam, L. H.	.60
B 4 Side Clevis on Beam R. H.	.60
B 5 Foot Rest	.60
B 6 Beam Gripe or Slide	1.05
B 7 Seat Spring Holder	.75
B 8 Circle for Caster Wheel	.60
B 9 Casting for Rear End Furrow Wheel Axle	.30
B 10 Spring and Dog Holder Caster Wheel	.60
B 11 Crank to Furrow Wheel	.30
B 12 Land Wheel Gripe for Lever	.60

B 13	Furrow Wheel Gripe for Lever	.60
B 15	O. S. Rolling Coulter Shank	.30
B 16	Trip Chain Evener	.30
B 17	Pole Iron Holder	.30
B 18	Forward Furrow Wheel Axle Holder	.75
B 19	Yoke for Caster Wheel	1.50
B 20	Dog for Caster Wheel	.30
B 21	Foot Rest Holder	.30
B 22	Jointer Block	.30
B 23	Pole Casting	.75
B 24	Furrow Wheel Casting	1.05
B 26	Trip Chain Hook	.15
B 27	Weed Hook Holder	.24
	Jointer Rigs	2 00
	Jointer Arm	1.50
	Jointer Mold	.40
	Jointer Point	.20
	Rolling Coulter Rig	4.00
	Rolling Coulter Blade	2.25
B 45	Rolling Coulter Yoke	1.05
	Steel Shank for Rolling Coulter	.50
	Knee Coulter Rig	1.50
	Knee Coulter Blade	1.25
B 28	Knee Coulter Block	.20
	Weed Hook, complete	1.05
	Wrench Hook Screw, complete	.60
	No. 122 Washer	.05
B 34	Lever Spring Slide	.30
B 36	Latch for Lever	.15
	Clevis Thimble	.05
	Scraper for Caster Wheel	.75
	Point for Scraper	.25
	R. C. 1 R. Coulter Block	.30
	R. C. 2 R. Coulter Block	.30
	Rolling Coulter Cones, pair	.20
	Rolling Coulter Sides or Axles	.50
	Spring on B 30 Casting	.10
	Pole	2.00
	Neck Yoke	1.00
	Tripletrees, complete	4.00
	* Evener, large	.75
	Doubletrees, small	.60
	Singletrees	.35

Small Clevises	.30
Inside Axle Washer	.25
Outside Axle Washer	.15
Spring Keys	.05
Lever Springs	.10
Bolts, all other kinds	.10

EXTRAS.

CHILLED PLOWS.

To insure against spurious Parts, see that our Trade Mark is on all Castings.



MOLDBOARDS.

Nos. 15, 15A, 16, 22, 23, 24, 26, 27A, 28, 30, 34, A3, A4, A6, 39, 40, 41, and 42	\$3.50
Nos. 18, 19, 20, 21, 29, 31, 37, A1, A2, and 20A	3.50
Nos. 32, 33, and 9	3.25
Nos. 17, 17A, 36 and 17B	2.50
No. 25	1.50
Nos. A4, 24, 26, 39, and 42 (steel)	4.50
Nos. 25A, 35, and 38	1.50

STANDARDS.

Nos. A1, A2, A3, A4, and 6	\$4.00
Nos. 15, 16, 22, and 23	3.75
Nos. 18, 19, 20 and 21	3.25
Nos. 15A, 26, 27A, 28, 30, 34, and 39	3.00
Nos. 40 and 42	3.50
Nos. 20A, 29, 31, 32, 33, and 37	2.75
Nos. 17, 36, and 38	2.25
Nos. 17A, 25, 25A, 35, and 17B	2.00
Frog for 24 and 240 steel beam plow, R. H.	2.50

LANDSIDES.

All Nos. (except those below)	\$1.00
Nos. 17, 17A, 36 and 38	.75
Nos. 25, 25A, 9 and 35	.50

PLAIN SHARES, GROUND AND BUFFED.

Nos. 25, 25A, and 35	\$.25
Nos. 17, 17A, 36, and 38	.40
All other numbers	.45
Plain Shares, full chilled	1.00

PLAIN SHARES, GROUND ONLY.

Nos. 25, 25A, and 35	\$.25
Cast Shares for "Big Injun," R. H. and L. H., B2, and B4	.40
Cast Shares for "Big Injun," R. H. and L. H., B1	.75
Cast Shares for Steel Walking Plow, R. or L., H2, and H4	.40
Cast Shares for Steel Walking Plow, R. or L. H3	.75
All other numbers	.35

CUTTER SHARES, GROUND AND BUFFED.

Nos. 17 and 17A	\$.45
Nos. 25 and 25A	.30
All other numbers	.50

CUTTER SHARES, GROUND ONLY.

Nos. 17 and 17A	\$.40
All other numbers	.45

PLAIN CAST STEEL SHARES.

Nos. A4, A6, 15, 15A, 16, 18, 19, 22, 26, 30, and 34	\$3.00
Nos. A1, A2, A3, 20, 20A, 21, 29, 31, 32, 33, and 37	2.50
Nos. 17, 17A, and 36	2.00

REVERSIBLE STEEL BAR POINTS.

24 inches long	\$1.00
Wings or Shares, Chilled, for Nos. 39, 40, 41, and 42, Ground only	.35
Same, Ground and Buffed	.45

CAST STEEL MARSH SHARES.

All numbers	\$3.50
Iron Marsh Shares, all numbers	1.25

STANDARD JOINTERS.

All numbers	\$2.00
Standard Jointer Arm, Cast iron	1.50
All numbers, Standard Jointers with Steel Moldboard and Point	2.50
Steel Jointer, Moldboard and Point, (combined)	.75
Standard Jointer Arm, Wrought iron	1.00
Standard Jointer Head, Malleable	.40
Standard Jointer Moldboard, Chilled	.40
Standard Jointer Points,	.20
Standard Jointer Block for Wrought Arm	.20
Standard Jointer Arm Bolt	.15

BEAM JOINTERS, MALLEABLE.

All numbers	\$2.00
Beam Jointer Holder, Malleable, Nos. 1 and 3	.80
Beam Jointer Standard, Malleable, Nos. 2 and 4	.60
Beam Jointer Moldboards, Chilled, A and B	.40
Beam Jointer Points, Chilled, A and B	.20
Beam Jointer Beam Bolt	.10
Beam Jointer Standard Bolt	.10

STANDARD KNEE COULTERS.

All numbers	\$1.50
Standard Knee Coultter Block	.20
Standard Knee Coultter Blade, Steel	1.25
Standard Knee Coultter Arm Bolt	.15

BEAM COULTERS.

All numbers	\$2.00
Beam Coultter Holder, Malleable	.80
Beam Coultter Steel Blade, hanging	1.00
Beam Coultter Beam Bolt	.10
Beam Coultter Blade Bolt	.10

WHEEL RIGS.

All numbers complete, with bolts	\$1.00
Wheels only	.40
Wheel Standard or Jacks, Cast or Malleable	.40
Wheel Axles or Arbors	.20
Wheel Axle Sand Caps	.05
Wheel Axle Bolt	.05

CLEVISES.

Nos. 17, 17A, 25, 25A, 35, 36, 38	\$.30
Nos. 9 and 24, Cast	.50
Nos. 9 and 24, 3-horse, with rod	1.00
Large Clevises	.35
Small Clevises	.15
Clevis Link	.10
Clevis for No. 24 and 240 Steel Beam, Chilled or Combination Plow, complete	.75
Jaws, pair	.50
Cross Clevis	.35

WRENCHES.

All numbers, Malleable	.20
All numbers, Screw	.60

BEAMS PLAIN.

Nos. A1, A2, A3, A4, and A6	\$1.50
Nos. 25 and 25A,	.75
Nos. 17, 17A, 33, 36 and 38	1.00
All other Wood Beams, plain	1.25
All other Wood Beams, complete	2.00
No. 9, Iron Beam	4.00
No. 24, Iron Beam	4.25
Malleable Beams, plain, Nos. 26, 27A, 15A, 39 and 40	3.50
Malleable Beams, complete, with a Clevis, Rig, Tail Casting, and Bolt	4.50
Beam Casting or tail piece rear end of beam	.40

HANDLES.

Handles, per pair, O. S. on top of Plow, complete	1.25
Handles, single, O. S. on top of Plow	.50
Handles, per pair, N. S.	1.50
Handles, single, N. S.	.50
Handle Rounds and Rods	.20
Handle Brace, Malleable, for O. S. Handles	.50
Handle Brace or Brace on Moldboard, Cast	.50
Handle Index, or casting between handles, New Style	.50
Handle Stretcher Bolt, between handles, lower end	.25
Handle Braces, N. S. Steel Plow, each	.50

SHIN PIECES, CHILLED.

Nos. 29, 30, 31, 32, 33, 34, 36, and 37	\$.25
---	--------

SHIN PIECES STEEL.

Nos. 20, 30, 31, 32, 33, 34, 36, and 37 \$.75

BOLTS.

Large Beam Bolts	\$.20
Small Beam Bolts	.10
Large Point Bolts, all numbers	.05
Jointer Point Bolts, all numbers	.05
Jointer Moldboard Bolts, all numbers	.05
Jointer Arm Bolts, all numbers	.15
Jointer Head Bolts, all numbers	.10
Coulter Arm Bolts, all numbers	.15
Large Moldboard Bolts, all numbers	.05
Long Landside Bolts, all numbers	.10
All Short Landside Bolts, all numbers	.05
Wheel Rig Bolts, through beam	.10
Wheel Axle Bolts, through axle	.10
Rear Beam Hook Bolts	.10
Tail Piece Bolts, through beam	.10
Tail Piece Bolt, through handle index	.05
Stretcher Bolts, all numbers	.20
Guide Wrench to Clevis	.10
Guide Pin to Clevis	.05

MISCELLANEOUS PARTS.

Draft Hooks for Wood Beam	\$.30
Draft Hooks for 3 Rod Beam	.30
Steel Set Screw, to hold Reversible Steel Bar Point	.25
Steel Nut for above Set Screw	.10
Adjustable Wing Shovel Plow Blades, Steel	3.00

COMMON POINTS.

We make for all plows (L. N.) or long nose points for hard, dry ground, and to insure this kind of points, order points with L. N. We also make narrow wing or stony land points for our plows, which are designated S. L. also wide wing points, which are designated by W. W. We have cutter points for all our chilled plows, (except those plows made with sloping landsides.)

CAST STEEL POINTS.

The following Plows are furnished with plain steel points, namely: Nos. 26, 27A, 30, 31, 32, 34, 35, 36, 37, A3, A4, and A6.

The following Plows are furnished, when desired, with steel marsh points, viz: Nos. 15, 15A, 16, 22, 26, 27A, and A4.

We stencil all steel marsh points with the word "Steel," and the number of the point upon them.

When ordering points be sure and give the number of the plow you desire them to fit, as points will only fit the plows they are expressly made for. Also in ordering repairs for any of our plows, be very particular and give the number of the plow, that you want such a repair to fit. By doing this you will avoid all delays for want of right numbers.

STEEL MOLDBOARDS ON CHILLED PLOWS.

Our Steel Moldboards are made of soft center syndicate steel. We furnish Steel Moldboards for the numbers A4, 24, 26, and 240 Plows. In ordering Steel Moldboards for the number A4 and 24 Plow, you should always order a Landside to go with the Moldboard, as the Landside used with the Chilled Moldboard will not fit with the Steel Moldboard.

NOTICE!

Goods warranted only against breakage caused by manifest defect in material, and to be constructed in a good workmanlike manner. All Plows to do good work when properly set up and handled according to printed directions. When Plows are reported as defective, or not doing good work, the right is reserved to send an expert to test them, and, if found defective in material or workmanship, we will pay the expense of the trip and test; but if they are found to work perfectly, and complaint was made because of improper usage, you are to pay such expense.

All our Steel, Chilled, or Combination Plows are warranted to do as good work—strictly first-class work, in all soils—as any other Plow of class of the Plow tried. If a purchaser fails to make a Plow do first-class work after one day's trial, and if after notice to the Gale Manufacturing Co., and sufficient time has been allowed to send an expert, they, or the dealer who sold the plow, fails to make it work as warranted, the Plow may be held subject to order of Gale Manufacturing Co., and the notes or money paid will be refunded.

Plow will be considered sold if no due complaint is made immediately after one day's use.

Breakage from defects will be made good by new parts only. Hardened Steel Shares and Moldboards are positively not warranted against breakage. When goods are put into the hands of the blacksmith, away from the factory, it is understood that all claims under this Warranty are surrendered. No returned Plows, parts or repairs, will be credited on account, but being manifestly defective will be made good, and returned free, or new goods sent in their place, as we may elect. Positively no allowances will be made for repairing done without our direct consent.

GENERAL INSTRUCTIONS.

We furnish a reasonable amount of printed matter free, delivered at express office in Albion, Mich., you to pay express charges on same. We will not pay for newspaper or other advertisement unauthorized by us, nor for printing of any kind except that furnished by us. We will not pay for telegraphing, except answers to messages we send, or unless in reference to parts short on machines shipped by us, or a similar case where we are entirely at fault. In such cases dispatches may be sent C. O. D., but in all other cases parties must pay charges on their messages.


We deliver all goods at depot free, and will endeavor to ship by cheapest route, getting freight as low as possible, but *will not be responsible for any charges*, neither will we agree to deliver machines at any specified rate of freight unless so specified in the contract. Goods in transit are at purchaser's risk. No goods to be returned to us, or to our branch houses, without our consent. No consignments made, or goods carried in hands of agents. We pay no freight or express charges.

Our responsibility ceases when we have delivered goods to the transportation companies, in good order, and received a receipt for the same. The fault after that is with the transportation companies, and claims for loss or damages should be made to them. No Plow will be received back as rejected, except the conditions of our warranty are observed. Second party to receive all goods, and pay charges from the factory. Should any plow or part prove defective from flaws, defective part may be returned to us, and we will replace it, provided you return imperfect or damaged parts to us by freight, together with full explanation. We do not guarantee such articles as are always liable to break by improper usage, or coming in contact with obstructions, but propose to replace only such articles as prove defective from flaws or defects in material discovered the first season.

Second party must examine his machines on arrival, and at once (within five days from receipt of goods), notify us if there is any shortage, and give us reasonable time to replace them, or we will not be responsible for shortage nor for incompleteness.

We give all our agents privilege to sell to all parties who come to their store to buy; but no agent has the privilege of canvassing for sales outside of territory named in his contract.

When ordering extras or repairs for either Chilled or Steel Plows, order by number, or number and letter stamped or cast on parts wanted; also state whether for "Big Injun" Sulky Plows, Walking Plows, Vineyard Gang Plows, or Gale Sulky Plows. When left-hand Plows are wanted, it should be so stated in the order, or right-hand Plows or parts will be sent. In ordering by letter, give the number of the Plow according to price list, and state whether for right or left hand. In sending Steel Plows to us for repairs, always put your address, as well as ours, on the shipping tag, and advise us by mail.





"BIG INJUN" SULKY PLOW.